



AIRBUS A320 - CAPABILITY LIST

SOURCING / PROCUREMENT / REPAIR

Please address your requests and orders to sales@spareways.com
<http://www.spareways.net/>

PARTNUMBER	DESCRIPTION	ATA
045-250-015	BOOMSET	23
045-250-025	BOOMSET	23
046-55-999-0231	BOOMSET	23
06282	WINDSHIELD LH	56
06282	WINDSHIELD LH	56
12664	VALVE CHECK	21
324425	VALVE INTAKE ANTI ICE	30
520550	PUMP RAT	29
623977	PUMP HYDRAULIC	29
693335	PUMP ELECTRICAL	29
762308	RAM AIR TURBINE	29
766352	RAM AIR TURBINE	29
887673	PUMP HYDRAULIC	29
913004	AIRSHOW CTRL UNIT	23
921000	DIGITAL INTERFACE UNIT	23
921006	DIGITAL INTERFACE UNIT	23
933260	PUMP RAT	29
974540	PUMP ELECTRICAL	29

2222604	ACCELEROMETER	31
4279198	MOTOR CONVERTER WIPER RH	30
4279204	MOTOR CONVERTER WIPER LH	30
4315542	LIGHT LANDING RETRACTABLE	33
5906732	GENERATOR APU	24
5909006	GENERATOR APU	24
5910047	GENERATOR APU	24
8900207	BOX CTRL	29
9260065	EMERGENCY BEACON AFR	23
9508175	VALVE FLOAT VENT	28
9811820	VALVE CHECK	28
34600017	EXTINGUISHER CARGO	26
86181007	EXTINGUISHER GTR	26
89794015	OXYGEN BOTTLE	35
89794050	OXYGEN BOTTLE	35
89794077	OXYGEN BOTTLE	35
114079014	VALVE SELECTOR DOOR	32
114079015	VALVE SELECTOR GEAR	32
114079016	VALVE SELECTOR DOOR	32
114079017	VALVE SELECTOR GEAR	32
114079018	VALVE SELECTOR GEAR	32
114079019	VALVE SELECTOR GEAR	32
114083003	VALVE VENT	32
114083004	VALVE VENT	32
114086001	VALVE CUT OUT	32
114086002	VALVE CUT OUT	32
114087004	VALVE BYPASS DOOR	32
114087005	VALVE BYPASS DOOR	32
114087006	VALVE BYPASS DOOR	32
114087007	VALVE BYPASS DOOR	32

114087008	VALVE BYPASS DOOR	32
114087009	VALVE BYPASS DOOR	32
114087010	VALVE BYPASS DOOR	32
114094001	ACTUATOR RETRACTION	32
114094007	ACTUATOR RETRACTION	32
114094008	ACTUATOR RETRACTION	32
114094228	CYLINDER SUB ASSEMBLY	32
114094240	PISTON ROD SUB ASSEMBLY	32
114094308	PISTON ROD SUB ASSEMBLY	32
114094600	CYLINDER SUB ASSEMBLY	32
114094604	GLAND	32
114094605	NUT	32
114094608	PISTON	32
114094635	RETRACTION PIN ACTUATOR	32
114094661	RETRACTION PIN ACTUATOR	32
114095001	ACTUATOR MLG LOCK STAY	32
114095004	ACTUATOR MLG LOCK STAY	32
114122009	ACTUATOR DOOR MLG	32
114122010	ACTUATOR DOOR MLG	32
114122011	ACTUATOR DOOR MLG	32
114122012	ACTUATOR DOOR MLG	32
114153001	VALVE RELIEF	32
114160005	JACK EJECTION	32
114193003	ACTUATOR RETRACTION MLG	32
114193004	ACTUATOR RETRACTION MLG	32
114193005	ACTUATOR RETRACTION MLG	32
114193006	ACTUATOR RETRACTION MLG	32
114193007	ACTUATOR RETRACTION MLG	32
114193008	ACTUATOR RETRACTION MLG	32
114193009	ACTUATOR RETRACTION MLG	32

114193200	CYLINDER SUB ASSEMBLY	32
114193240	CYLINDER SUB ASSEMBLY	32
114193244	PISTON ROD SUB ASSEMBLY	32
114193247	PISTON ROD SUB ASSEMBLY	32
114193600	CYLINDER SUB ASSEMBLY	32
114193601	PISTON ROD SUB ASSEMBLY	32
114193602	GLAND	32
114193603	PISTON	32
114193604	NUT	32
114193610	RETRACTION PIN ACTUATOR	32
114193637	RETRACTION PIN ACTUATOR	32
114193641	CYLINDER SUB ASSEMBLY	32
114193642	GLAND	32
201117017	UPLOCK MLG LH	32
201117018	UPLOCK MLG RH	32
201117021	UPLOCK MLG LH	32
201117022	UPLOCK MLG RH	32
201117025	UPLOCK MLG LH	32
201117026	UPLOCK MLG RH	32
201590001	ACTUATOR MLG RETRACTION	32
201590002	ACTUATOR MLG RETRACTION	32
201590200	CYLINDER SUB ASSEMBLY	32
201590204	PISTON ROD SUB ASSEMBLY	32
201590205	PISTON ROD SUB ASSEMBLY	32
201590900	RETRACTION PIN ACTUATOR	32
201590901	RETRACTION PIN ACTUATOR	32
201590906	CYLINDER SUB ASSEMBLY	32
201590908	PISTON ROD SUB ASSEMBLY	32
201590909	PISTON	32
201590910	NUT	32

201590913	GLAND	32
201697601	CYLINDER SUB ASSEMBLY	32
201697603	CYLINDER SUB ASSEMBLY	32
1663214301	COMPUTER PROBE HEAT	30
1982660109	DISPLAY MANAGEMENT COMPUTER	31
1982660116	DISPLAY MANAGEMENT COMPUTER	31
3906130302	DISPLAY UNIT FULL COLOR	31
3906130402	DISPLAY UNIT FULL COLOR	31
3907130302	DISPLAY UNIT FULL COLOR	31
3907130402	DISPLAY UNIT FULL COLOR	31
3945122609	COMPUTER ELEVATOR AILERON	27
3945123506	COMPUTER ELEVATOR AILERON	27
3945123608	COMPUTER ELEVATOR AILERON	27
3945123609	COMPUTER ELEVATOR AILERON	27
3945128102	COMPUTER ELEVATOR AILERON	27
3945128206	COMPUTER ELEVATOR AILERON	27
3945128209	COMPUTER ELEVATOR AILERON	27
3957985114	EIU - ENGINE INTERFACE UNIT	73
3957985115	EIU - ENGINE INTERFACE UNIT	73
3957985205	EIU - ENGINE INTERFACE UNIT	73
3957985206	EIU - ENGINE INTERFACE UNIT	73
9615325032	DMC - DISPLAY MANAGEMENT COMPUTER	31
9615325040	DMC - DISPLAY MANAGEMENT COMPUTER	31
9615325050	DMC - DISPLAY MANAGEMENT COMPUTER	31
9615433403	COMPUTER DISPLAY HEAD UP	34
0102ME2GE	SENSOR TAT	34
0154JU	PROBE INLET	73
01N65900	EMERGENCY LOCATOR BEACON	23
01N65920	EMERGENCY TRANSMITTER LOCATOR	23
046-55-999-0231	BOOMSET	23

064-50000-0202	TRANSCEIVER VHF COM	23
064-50000-0505	TRANSCEIVER VHF COM	23
064-50000-2051	TRANSCEIVER VHF COM	23
065-50001-0200	CSU-COMMAND SENSOR UNIT	27
066-01127-1101	TRANSPONDER ATC MODE S	34
066-01127-1301	TRANSPONDER ATC MODE S	34
066-01127-1402	TRANSPONDER ATC MODE S	34
066-50000-2120	COMPUTER TCAS	34
066-50000-2220	COMPUTER TCAS	34
066-50007-0232	TRANSCEIVER RADIO ALTIMETER	34
066-50008-0407	TRANSCEIVER WEATHER RADAR	34
066-50008-0408	TRANSCEIVER WEATHER RADAR	34
066-50008-0409	TRANSCEIVER WEATHER RADAR	34
066-50012-0202	RECEIVER VOR-MARK	34
066-50012-0212	RECEIVER VOR-MARK	34
066-50012-1212	RECEIVER VOR-MARK	34
066-50013-0202	INTERROGATOR DME	34
066-50013-0232	INTERROGATOR DME	34
066-50013-1212	INTERROGATOR DME	34
066-50013-1222	INTERROGATOR DME	34
066-50014-0202	RECEIVER ADF	34
066-50014-1202	RECEIVER ADF	34
066-50029-1161	MMR - MULTI MODE RECEIVER	34
0711480-004	VALVE HCU SHUTOFF	78
071-50001-8104	ANTENNA TCAS	34
0725185	COUPLING REFUEL	28
0727540	CAP COUPLING REFUEL	28
0851HL	PROBE PITOT	34
0861ED	SENSOR ANGLE OF ATTACK	34
0861ED2	SENSOR ANGLE OF ATTACK	34

088256-04644	ACCUMULATOR BRAKE	32
1-002-0102-1830	INVERTER STATIC	24
1-001-0102-0296	INVERTER STATIC	24
1010099-6	BOILER	25
1010099-6-1	BOILER	25
1010099-6-2	BOILER	25
100-2500-04	CONTROLLER CDSS	23
100-2513-090-08	CAMERA ASSY SURVEILLANCE	44
10-1236-00	FEEDLINE ANTENNA	23
10170-0202	INDICATOR FUEL QUANTITY	28
10173-0202	PRESELECTOR	28
102-00090	SENSOR OIL TEMPERATURE	79
106-1-1100-02	ACTUATOR APU AIR INTAKE FLAP	49
10-376501-000	SLEEVE ASSY AXLE NLG	32
10-451701-000	ACTUATOR RETRACTION	32
10-452701-000	ACTUATOR LOCK STAY	32
10-617075-6	EXCITER IGNITION ETHOPS	49
1070B0000-01	ACTUATOR FLAP	27
1070B0000-02	ACTUATOR FLAP	27
1070B0000-04	ACTUATOR FLAP	27
1071A0000-02	ACTUATOR FLAP	27
1071B0000-01	ACTUATOR FLAP	27
1071B0000-02	ACTUATOR FLAP	27
1071B0000-04	ACTUATOR FLAP	27
1072A0000-01	ACTUATOR FLAP	27
1072A0000-02	ACTUATOR FLAP	27
1072A0000-04	ACTUATOR FLAP	27
1073A0000-01	ACTUATOR FLAP	27
1073A0000-02	ACTUATOR FLAP	27
1073A0000-04	ACTUATOR FLAP	27

1074A0000-01	ACTUATOR FLAP	27
1074A0000-02	ACTUATOR FLAP	27
1074A0000-03	ACTUATOR FLAP	27
1111A0000-01	VALVE-SOLENOID	27
114079009AB	VALVE SELECTOR GEAR	32
114079010AB	VALVE SELECTOR DOOR	32
114079016	SELECTOR DOOR ELECTRO HYD	32
114079018	SELECTOR DOOR ELECTRO HYD	32
114079019	SELECTOR DOOR ELECTRO HYD	32
114083003	VALVE VENT	32
114083004	VALVE VENT	32
114086001	VALVE CUT OUT	32
114086002	VALVE CUT OUT	32
114087005	VALVE BYPASS DOOR	32
114087006	VALVE BYPASS DOOR	32
114087007	VALVE BYPASS DOOR	32
114087008	VALVE BYPASS DOOR	32
114087009	VALVE BYPASS DOOR	32
114087010	VALVE BYPASS DOOR	32
114095004	ACTUATOR-LOCK STAY	32
114095004-010	ACTUATOR MLG LOCK STAY	32
114122011	ACTUATOR DOOR MLG	32
114122012	ACTUATOR DOOR MLG	32
114122014	ACTUATOR DOOR MLG	32
114122015	ACTUATOR DOOR MLG	32
114151004	VALVE HIGH PRESSURE	29
114160004A	JACK EJECTION	32
1151324-1M563	ELT - EMERGENCY LOCATOR TRANSMITTER	25
1152682-3	ELT - EMERGENCY LOCATOR TRANSMITTER	25
115370-0105	FDC - FLIGHT CTRL DATA CONCENTRER	27

115370-0106	FDC - FLIGHT CTRL DATA CONCENTRER	27
115370-1016	FDC - FLIGHT CTRL DATA CONCENTRER	27
115370-1118	FDC - FLIGHT CTRL DATA CONCENTRER	27
115370-1216	FDC - FLIGHT CTRL DATA CONCENTRER	27
115370-1318	FDC - FLIGHT CTRL DATA CONCENTRER	27
115370-1319	FDC - FLIGHT CTRL DATA CONCENTRER	27
115370-1519	FDC - FLIGHT CTRL DATA CONCENTRER	27
115370-1520	FDC - FLIGHT CTRL DATA CONCENTRER	27
115370-1521	FDC - FLIGHT CTRL DATA CONCENTRER	27
1158000-21	VALVE REFUEL	28
1158000-21R	VALVE REFUEL	28
1158000-45	VALVE REFUEL	28
11-841193-2	HEAT EXCHANGER OIL FUEL MAIN	79
11-841193-3	HEAT EXCHANGER OIL FUEL MAIN	79
11-841193-4	HEAT EXCHANGER OIL FUEL MAIN	79
11-851154	PRECOOLER BLEED AIR	36
11-851154-5	PRECOOLER BLEED AIR	36
11-851154-6	PRECOOLER BLEED AIR	36
1201-01-00	COFFEE MAKER	25
1201-01-00SWRA	COFFEE MAKER PILLOW	25
12134-00	DETECTOR FIRE	26
1263A0000-02	AIR CYCLE MACHINE	21
1263A0000-03	AIR CYCLE MACHINE	21
1266-100	SWITCH DIFFERENTIAL PRESSURE	52
12664	VALVE CHECK	21
121664-3	ACTUATOR BALLSCREW	75
121664-4	ACTUATOR BALLSCREW	75
121664-5	ACTUATOR BALLSCREW	75
121664-8	ACTUATOR BALLSCREW	75
121664-10	ACTUATOR BALLSCREW	75
121666-3	ACTUATOR BALLSCREW MASTER	75

121666-4	ACTUATOR BALLSCREW MASTER	75
121666-6	ACTUATOR BALLSCREW MASTER	75
121666-7	ACTUATOR BALLSCREW MASTER	75
121666-8	ACTUATOR BALLSCREW MASTER	75
121666-13	ACTUATOR BALLSCREW MASTER	75
121666-14	ACTUATOR BALLSCREW MASTER	75
121666-16	ACTUATOR BALLSCREW MASTER	75
121666-17	ACTUATOR BALLSCREW MASTER	75
121666-18	ACTUATOR BALLSCREW MASTER	72
121666-19	ACTUATOR BALLSCREW MASTER	75
121666-21	ACTUATOR BALLSCREW MASTER	75
123100-3	PDU-POWER DRIVE UNIT	25
125A2	VISUAL INDICATOR	79
125A3	VISUAL INDICATOR	79
1298A0000-01	VALVE CHECK	21
1303A0000-03	VALVE FLOW CONTROL	21
1303A0000-04	VALVE FLOW CONTROL	21
1312A0000-01	VALVE BYPASS	21
1312B0000-01	VALVE BYPASS	21
1312B0000-02	VALVE BYPASS	21
1320A0000-01	VALVE TRIM AIR	21
1320A0000-02	VALVE TRIM AIR	21
1330622-070	SEAT - THIRD OCCUPANT	25
1330622-070-1	SEAT - THIRD OCCUPANT	25
1330622-070C	SEAT - THIRD OCCUPANT	25
1330622V	SEAT - THIRD OCCUPANT	25
1330622V01	SEAT - THIRD OCCUPANT	25
1330622VG	SEAT - THIRD OCCUPANT	25
133300	STRUCTURE BACKREST ASSY	25
1374-100-000	RECORDER EQAR	31
1374-100-002	RECORDER EQAR	31

1374-200-002	RECORDER EQAR	31
1407KID01-02	INDICATOR FUEL QTY	28
1407KID02-03	INDICATOR FUEL QTY	28
1407KIDC1-01	INDICATOR FUEL QTY	28
1412KID01-02	INDICATOR FUEL QTY	28
1412KID02-03	INDICATOR FUEL QTY	28
1418KID01-03	INDICATOR FUEL QTY	28
14310-301	TOILET ASSY AFT	38
14310-303	TOILET ASSY FWD	38
14320-001-1	TOILET ASSY VACUUM LH	38
14320-001B1	TOILET ASSY VACUUM LH	38
14320-001B2	TOILET ASSY VACUUM RH	38
14320-001C1	TOILET ASSY VACUUM LH	38
14320-001C2	TOILET ASSY VACUUM RH	38
14320-001-2	TOILET ASSY	38
14320-002-1	TOILET ASSY	38
14320-002A1	TOILET ASSY VACUUM RH	38
14320-002A2	TOILET ASSY VACUUM RH	38
14320-002B1	TOILET ASSY VACUUM LH	38
14320-002B2	TOILET ASSY VACUUM LH	38
14320-002C1	TOILET ASSY VACUUM LH	38
14320-002C2	TOILET ASSY VACUUM RH	38
14320-002-2	TOILET ASSY	38
14320-230-201	FLUSH VALVE	38
14320-230-203	FLUSH VALVE	38
14320-230-205	FLUSH VALVE	38
14320-230-207	VALVE ASSY	38
14330-004A1	TOILET ASSY VACUUM LH	38
14330-004A2	TOILET ASSY VACUUM RH	38
14330-004B1	TOILET ASSY VACUUM LH	38
14330-004B2	TOILET ASSY VACUUM RH	38

14330-008-1	TOILET ASSEMBLY LH	38
14330-008-2	TOILET ASSEMBLY RH	38
14330-350	GENERATOR VACUUM	38
14330-375	GENERATOR VACUUM	38
14400-230A1	TOILET ASSY VACUUM LH	38
14400-230A2	TOILET ASSY VACUUM RH	38
14400-230B1	TOILET ASSY VACUUM LH	38
14400-230B2	TOILET ASSY VACUUM RH	38
14400-230C1	TOILET ASSY VACUUM LH	38
14400-230C2	TOILET ASSY VACUUM RH	38
14320-230-205	VALVE ASSY	38
14330-004A1	TOILET ASSY	38
14330-004A2	TOILET ASSY	38
14330-004B1	TOILET ASSY	38
14330-004B2	TOILET ASSY	38
14330-004C1	TOILET ASSY	38
14330-004C2	TOILET ASSY	38
14330-004C4	TOILET ASSY	38
14330-008-1	TOILET ASSY	38
14330-050	VALVE FLUSH	38
14330-170	VALVE ASSY	38
14330-230	VALVE ASSY	38
14330-375	GENERATOR VACUUM	38
14400-230-1	TOILET ASSY	38
14400-230-2	TOILET ASSY	38
14400-230A1	TOILET ASSY	38
14400-230A2	TOILET ASSY	38
14400-230B2	TOILET ASSY	38
14401-029	FILTER	38
14401-085	SEPARATOR WATER	38
14403-003C	TRANSMITTER LEVEL	38

14403-085	SENSOR LEVEL	38
14403-125	SENSOR LEVEL	38
14404-010	VACUUM CONTROLLER SYSTEM	38
14404-011	VACUUM CONTROLLER SYSTEM	38
14404-011-1	VACUUM CONTROLLER SYSTEM	38
14404-011B	VACUUM CONTROLLER SYSTEM	38
144-171-000-031	TRANSDUCER	77
144-171-000-032	TRANSDUCER	77
15-40F	PBE SMOKE HOOD	35
15-40F-11	PBE SMOKE HOOD	35
1553A9900-01	MANIFOLD HP	29
1553A9900-02	MANIFOLD HP	29
1554A9900-01	MANIFOLD HP	29
1555B9900-01	MANIFOLD HP	29
1556A9900-02	MANIFOLD HP	29
1556A9900-04	MANIFOLD HP	29
1559A9900-01	MANIFOLD HP	29
1559A9900-02	MANIFOLD HP	29
1567A0000-01	VALVE MANUAL	52
15800-323	TOILET VALVE ANTI SYPHON	38
15800-348	TOILET RINSE VALVE	38
15800-348A	TOILET RINSE VALVE	38
15800-358	TOILET RINSE VALVE	38
15800-440	TOILET RINSE VALVE	38
160494-1	COOLER OIL	49
1605100	VISUAL INDICATOR	79
1605100-01	VISUAL INDICATOR	79
16800-00-00	SEAT - THIRD OCCUPANT	25
16800-01-00	SEAT - THIRD OCCUPANT	25
16844-000	COOLER IDG	74

1696M74P01	TRANSMITTER FUEL FLOW	73
1700667D	GAPCU - GROUND AUXILIER POWER CONTROL UNIT	24
17300G09	FUEL DIVER & RETURN VALVE	73
17300G11	FUEL DIVER & RETURN VALVE	73
1778MK1	ACTUATOR SLAVE	75
1779MK2	VALVE SCAVENGE	79
1803B0000-01	CONTROLLER AIR CONDITION	21
1803B0000-02	CONTROLLER AIR CONDITION	21
1803B0000-03	CONTROLLER AIR CONDITION	21
1803B0000-04	CONTROLLER-AIR CONDITIONI	21
1806B0000-02	VALVE ASSY FLOW CONTROL	21
1806D0000-01	VALVE ASSY FLOW CONTROL	21
1809A0000-01	ACTUATOR INLET	21
1814A0000-02	MACHINE AIR CYCLE	21
1816B0000-01	CHAMBER AIR PLENUM	21
1816B0000-02	CHAMBER AIR PLENUM	21
18330904-2	GAUGE NITROGEN PRESSURE	29
1905A0000-01	VALVE SAFETY	32
195PN01	INDICATOR TRIM RUDDER	22
195PN01Y01	INDICATOR TRIM RUDDER	22
196PN01Y02	INDICATOR TRIM RUDDER	22
1982660116	DMC - DISPLAY MANAGEMENT COMPUTER	31
1B1000-1GS	INVERTER STATIC	24
1X0456177-00	LED RUNWAY TURNOFF LIGHT	33
1X2005012-00	LOADING AREA LIGHT	33
1X2005097-00	LIGHT LOGO	33
1X2005097-01	LED LIGHT LOGO LH	33
1X2005097-02	LED LIGHT LOGO RH	33
2000866-2	STARTER APU	49
2000866-3	STARTER APU	49
200301E00000206	SFCC - SLAT FLAP CONTROL	27

200301E00000307	SFCC - SLAT FLAP CONTROL	27
200301E00000308	SFCC - SLAT FLAP CONTROL	27
200301E00000309	SFCC - SLAT FLAP CONTROL	27
201059001	LOCK SPRING	32
201117018	UPLOCK MLG RH	32
201117022	UPLOCK MLG RH	32
201117025	UPLOCK MLG LH	32
201117026	UPLOCK MLG RH	32
201122008	UPLOCK DOOR MLG	32
201122009	UPLOCK DOOR MLG	32
2013-1A	BATTERY PACK	33
201399007	ENHANCED HARNESS LH 1M	32
201399008	ENHANCED HARNESS RH 1M	32
201399200	HARNESS LH 1M	32
201399201	HARNESS RH 1M	32
201400005	HARNESS ENHANCED LH 2M	32
201400006	ENHANCED HARNESS RH 2M	32
201400200	HARNESS LH 2M	32
201400201	HARNES RH 2M	32
201401200	HARNESS AXLE 1M	32
201401201	HARNESS AXLE 1M	32
201402200	HARNESS AXLE 2M	32
201402201	HARNESS AXLE 2M	32
201419001-020	DAMPER TORQUE LINK MLG	32
20145-0102	PROBE FQIS	28
20149-0101	DUAL COMPENSATOR	28
20150-0101	ULTRA COMPENSATOR	28
2000866-4	STARTER APU	49
201590001	ACTUATOR RETRACTION MLG	32
201590002	ACTUATOR RETRACTION MLG	32

201590002-010	ACTUATOR RETRACTION MLG	32
201590002-020	ACTUATOR RETRACTION MLG	32
201590003	ACTUATOR RETRACTION MLG	32
201590004	ACTUATOR RETRACTION MLG	32
201590900	RETRACTION ACTUATOR PIN	32
201590901	RETRACTION ACTUATOR PIN	32
2040029-104	VALVE DUAL FLOW AND SHUT	47
2041167-3709	INTERROGATOR DME	34
2041168-7513	RECEIVER ADF	34
2041214-0401	TRAY MOUNTING WR XCVR	34
2041217-0418	WRCP - TRANSCEIVER WEATHER RADAR CTRL PANEL	34
2041220-0410	WRCP - TRANSCEIVER WEATHER RADAR CTRL PANEL	34
2041220-0424	WRCP - TRANSCEIVER WEATHER RADAR CTRL PANEL	34
2041220-3231	WRCP - TRANSCEIVER WEATHER RADAR CTRL PANEL	34
2041223-0410	WRCP - TRANSCEIVER WEATHER RADAR CTRL PANEL	34
2041223-0411	WRCP - TRANSCEIVER WEATHER RADAR CTRL PANEL	34
2041223-0424	WRCP - TRANSCEIVER WEATHER RADAR CTRL PANEL	34
2041230-3518	RECEIVER ILS	34
2041230-3521	RECEIVER ILS	34
2041230-3532	RECEIVER ILS	34
2041231-3610	RECEIVER VOR-MARK	34
2041231-3622	RECEIVER VOR-MARK	34
2041444-0403	WEATHER RADAR DRIVE UNIT	34
2041444-0404	WEATHER RADAR DRIVE UNIT	34
2041446-0401	ANTENNA WEATHER RADAR	34
2056C0000-01	CHAMBER AIR PLENUM	21
2060017-101	AIR SEPARATION MODULE	47
2060017-102	AIR SEPARATION MODULE	47
2060017-103	AIR SEPARATION MODULE	47
2068599-0705	WXR TRANSCEIVER PLATE SWITCH	34
2056A0000-02	PLENUM CHAMBER	21

2056C0000-01	PLENUM CHAMBER	21
205PN01	DC VOLTMETER	24
205PN01Y01	DC VOLTMETER	24
206PN01	DC VOLTMETER	24
20781-01	MOTOR AUTO	21
20781-02	MOTOR AUTO	21
20790-01AA	VALVE OUTFLOW	21
20790-02AC	VALVE OUTFLOW	21
20790-03AC	VALVE OUTFLOW	21
20790-20BA	VALVE OUTFLOW	21
20791-02AB	CONTROLLER PRESSURE CABIN	21
20791-03AB	CONTROLLER PRESSURE CABIN	21
20791-13AC	CONTROLLER PRESSURE CABIN	21
20791-13AD	CONTROLLER PRESSURE CABIN	21
2100-1226-02	CVR COCKPIT VOICE RECORDER	23
2100-1228-02	CVR COCKPIT VOICE RECORDER	23
2100-4043-02	SSFDR SOLID STATE FDR	31
2100-4245-02	SSFDR SOLID STATE FDR	31
21036-01	VALVE CHECK	21
21071-01AA	ELECTONIC BOX	21
21071-02AC	ELECTONIC BOX	21
21071-03AC	ELECTONIC BOX	21
210TS07Y	LEVER CONTROL	32
210TS07Y01	LEVER CONTROL	32
215TS07Y00	LEVER CONTROL	32
21SN04-275A	SWITCH	79
21SN04-298A	SWITCH	79
21SN04-300B	SWITCH	79
2-1684	BRAKE ASSY MLG CARBON	32
215TS07Y00	LEVER CONTROL	32
20-678	PIN TORQUE	32

2231500-18	MANAGEMENT UNIT ACARS	23
2231500-1A	MANAGEMENT UNIT ACARS	23
2234320-01-01	FDIMU-FLIGHT DATA INTERFA	31
2234320-02-02	FDIMU-FLIGHT DATA INTERFA	31
2243800-362	QAR-QUICK ACCESS RECORDER	31
22715-000-02	CYLINDER-ACTUATING,NLG DO	32
2290B010000	VALVE IP CHECK	36
2290B020000	VALVE IP CHECK	36
2291A010000	VALVE IP CHECK	36
2291A030000	VALVE IP CHECK	36
2293B010000	VALVE IP CHECK	36
2293B020000	VALVE IP CHECK	36
23545-01BA	BOX ELECTRONIC	21
2368-501	OUTLET AIR BLACK	21
238-0101-501	COWL ASSY-AIR INLET	71
238-0101-503	COWL ASSY-AIR INLET	71
238-0101-505	NOSE COWL	71
238-1105-505	THRUST REVERSER LH	78
238-1105-511	THRUST REVERSER LH	78
238-1106-505	THRUST REVERSER RH	78
238-1106-511	THRUST REVERSER RH	78
238-2101-501	COWL ASSY AIR INLET	71
238-2101-503	COWL ASSY AIR INTAKE	71
238-2101-505	COWL ASSY AIR INLET	71
238D1014-503	VALVE ANTI ICE	30
238D1025-501	STRUT ASSY FAN COWL	71
238D1025-507	STRUT ASSY FAN COWL	71
238D1025-511	STRUT ASSY FAN COWL	71
241-191-000-031	EVMU - ENGINE VIBRATION MONITOR UNIT	77
241-191-000-041	EVMU - ENGINE VIBRATION MONITOR UNIT	77
241-211-000-021	EVMU - ENGINE VIBRATION MONITOR UNIT	77

241-246-022-004	EVMU - ENGINE VIBRATION MONITOR UNIT	77
241-247-012-005	EVMU-ENGINE VIBRATION MON	77
241-247-013-005	EVMU-ENGINE VIBRATION MON	77
2438-89-00	ANTENNA VDR	23
24E507009G01	HEATHER WATER	38
24E507009G02	HEATHER WATER	38
24E507009G03	HEATHER WATER	38
24F5202	OIL TANK	73
2510144-07-03	SEAT PILOT ELECTRIC	25
2510144-27-01	SEAT PILOT LH	25
2510144-33-01	SEAT PILOT LH	25
2510144-38-01	SEAT PILOT LH	25
2510144-40-03	SEAT PILOT	25
2510144-43-01	SEAT PILOT LH	25
2510144-53-01	SEAT PILOT LH	25
2510144-54-03	SEAT PILOT	25
2510145-27-01	SEAT CO PILOT RH	25
2510145-33-01	SEAT CO PILOT RH	25
2510145-38-01	SEAT CO PILOT RH	25
2510145-43-01	SEAT CO PILOT RH	25
2510145-53-01	SEAT CO PILOT RH	25
2510154-00-00	SEAT - FOURTH OCCUPANT	25
2510154-01-00	SEAT - FOURTH OCCUPANT	25
2510154-03-00	SEAT - FOURTH OCCUPANT	25
252CA01C1-02Y1	CONTACTOR THREE POLE	24
25975-000	BOX	77
2610-13-1	CLOCK ELECTRONIC	31
2632-82	ANTENNA ELT	25
2651A0000-01	MANIFOLD GROUND SERVICE	21
2652A0000-01	MANIFOLD GROUND SERVICE	21
2687A0000-01	SENSOR PRESSURE	21

2695A0000-01	SENSOR PRESSURE	21
2696A0000-01	SENSOR PRESSURE	21
2704506-1	MOTOR STATER	49
2704506-2	MOTOR STATER	49
2704506-4	MOTOR STATER	49
27-457	RUDDER TRIM CONTROL SWITCH	27
267-100	AIR CHILLER	25
267-16	AIR CHILLER	25
267-500	AIR CHILLER	25
285T0022-43	PANEL ASSY AUDIO SELECTOR	23
285T0022-44	PANEL ASSY AUDIO SELECTOR	23
285T0855-5	FLEET DECK ACCESS CONTROL MODULE	52
2944T100-1	PDU - POWER DIRVE UNIT	25
2944T100-3	PDU - POWER DIRVE UNIT	25
2955530-1	ROLLER PDU	25
2955810-1	ROLLER PDU	25
2955810-3	ROLLER PDU	25
2955T100-5	PDU - POWER DIRVE UNIT	25
2955T100-7	PDU - POWER DIRVE UNIT	25
2955T100-9	PDU - POWER DIRVE UNIT	25
2980192100000	FAUCET ASSY WATER	38
2980332100100	FAUCET ASSY WATER	38
2980372100000	FAUCET ASSY WATER	38
2995-402-00-10	SHUNT	24
29578	FILTER-PILOT VALVE	30
2A0526	VALVE FUEL DISTRIBUTION	73
2A2159	THERMOCOUPLE	77
2A2160	THERMOCOUPLE	77
2A3343	PROBE INLET	73
2A3580	BOX	77

2A4248	EEC - ELECTRIC ENGINE CTRL	73
2A4249	EEC - ELECTRIC ENGINE CTRL	73
2A4253	EEC - ELECTRIC ENGINE CTRL	73
2A4276	EEC - ELECTRIC ENGINE CTRL	73
2A4277	EEC - ELECTRIC ENGINE CTRL	73
2A4279	EEC - ELECTRIC ENGINE CTRL	73
2A4280	EEC - ELECTRIC ENGINE CTRL	73
2A4328	THERMOCOUPLE	77
2A4337	BOX	77
2A4355	EEC-ELECTR ENG CTRL	73
2LA002606-01	LIGHT INSPECTION	33
2LA003968-00	LIGHT ANTICOLLISION	33
2LA005127-01	LIGHT EMERGENCY OVERWING	33
2LA005127-10	LIGHT EMERGENCY OVERWING	33
2LA005128-01	LIGHT EMERGENCY OVERWING	33
2LA005128-10	LIGHT EMERGENCY OVERWING	33
2LA005303-05	TAIL STROBE LIGHT	33
2LA005308-05	WING STROBE LIGHT	33
2LA005413-01	LIGHT EMERGENCY OVERWING	33
2LA005413-10	LIGHT EMERGENCY OVERWING	33
2LA005414-01	LIGHT EMERGENCY OVERWING	33
2LA005414-10	LIGHT EMERGENCY OVERWING	33
2LA005482-00	REFUEL LIGHT	33
2LA005541-10	FLOODLIGHT UNIT CAPTAIN	33
2LA005541-11	FLOODLIGHT UNIT CAPTAIN	33
2LA005542-20	LIGHT-MAIN INSTRUMENT PANEL	33
2LA005542-50	LIGHT-MAIN INSTRUMENT PANEL	33
2LA005543-10	FLOODLIGHT UNIT FIRST OFF	33
2LA005543-11	FLOODLIGHT UNIT FIRST OFF	33
2LA402515-00	STROBE LIGHT ANTICOLLISION	33

2LA403700-01	REAR NAVIGATION LIGHT	33
2LA403700-02	REAR NAVIGATION LIGHT	33
2LA403702-01	REAR NAVIGATION LIGHT	33
2LA403702-02	REAR NAVIGATION LIGHT	33
2LA455010-00	STROBE LIGHT	33
2LA455968-01	LED BEACON LIGHT	33
2LA456223-01	LED WING STROBE LIGHT	33
2LA456241-00	LED REARWARD NAVIGATION & STROBE LIGHT	33
2LA456292-01	LED TAXI LIGHT	33
2LA456335-01	LED WING ENGINE SCAN LIGHT LH	33
2LA456335-02	LED WING ENGINE SCAN LIGHT RH	33
2LA456342-01	LED LOGO LIGHT LH	33
2LA456342-02	LED LOGO LIGHT RH	33
2LA456343-00	LED LOGO LIGHT RH	33
2LA456500-01	LED NAVIGATION LIGHT - WING TIP LH	33
2LA456500-02	LED NAVIGATION LIGHT - WING TIP RH	33
2LA456509-02	LED WING STROBE LIGHT - SHARKLET LH	33
2LA456510-01	LED RUNWAY TURNOFF LIGHT	33
2LA456510-02	LED WING STROBE LIGHT - SHARKLET RH	33
2LA456510-03	LIGHT UNIT STROBE RH	33
3-1470	WHEEL NLG	32
3-1470-1	WHEEL NLG	32
3-1530	WHEEL MLG	32
3-1530-1	WHEEL MLG	32
3-1530-2	WHEEL MLG	32
3-1530-3	WHEEL MLG	32
3-1530-4	WHEEL MLG	32
3-1530-5	WHEEL MLG	32
3-1530-6	WHEEL MLG	32
3-1530-7	WHEEL MLG	32

3-1531	WHEEL NLG	32
3-1531-1	WHEEL NLG	32
3-1531-2	WHEEL NLG	32
3-1531-3	WHEEL NLG	32
30042-0000-0202	FUEL LEVEL SENSING UNIT	28
3001-01-111	LINEAR ACCELEROMETER	28
30030-000	THERMOCOUPLE	28
30040-000	BOX	28
30042-0601	FUEL LEVEL SENSING UNIT	28
30-1706-1	LIGHT READY FOR FUEL	28
301-3017	BATTERY PACK	24
301-776-306-0	ACTUATOR BALLSCREW	75
301-780-702-0	HEAT EXCHANGER OIL FUEL MAIN	79
301-780-703-0	HEAT EXCHANGER OIL	79
301-780-704-0	HEAT EXCHANGER OIL	79
301-789-101-0	HEATER SERVO FUEL	73
301-789-102-0	SERVO FUEL HEATER	73
301-790-101-0	COOLER IDG OIL	73
301-791-301-0	ACTUATOR BALLSCREW MASTER	75
301-791-302-0	ACTUATOR BALLSCREW MASTER	75
301-792-703-0	ACTUATOR BALLSCREW MASTER	75
301-793-901-0	ACTUATOR BALLSCREW MASTER	75
301-793-902-0	ACTUATOR BALLSCREW MASTER	75
301-793-951-0	ACTUATOR BALLSCREW MASTER	75
301-793-952-0	ACTUATOR BALLSCREW MASTER	75
301-799-403-0	VISUAL INDICATOR	79
301-800-401-0	CHIP DETECTOR	79
301-807-203-0	FILTER-FUEL DOWN STREAM	73
3022053-000	PUMP HYDRAULIC	29
3022053-001	PUMP HYDRAULIC	29

3031863-001	PUMP HYDRAULIC ENGINE DRIVEN	29
30320-0203	COMPUTER-FUEL QTY INDIC	28
304640-3	ELECTRONIC CONTROL BOX	49
304817-2	ELECTRONIC CONTROL BOX	49
30973-242	VALVE ELECTRO	27
30973-262	VALVE ELECTRO	27
30983-242	VALVE ELECTRO	27
30983-262	VALVE ELECTRO	27
31073-052	SERVO CONTROL AIRLERON	27
31073-054	SERVO CONTROL AIRLERON	27
31073-055	SERVO CONTROL AIRLERON	27
31073-058	SERVO CONTROL AIRLERON	27
31073-060	SERVO CONTROL AIRLERON	27
31073-061	SERVO CONTROL AIRLERON	27
31073-062	SERVO CONTROL AIRLERON	27
31073-063	SERVO CONTROL AIRLERON	27
31073-064	SERVO CONTROL AIRLERON	27
31073-065	SERVO CONTROL AIRLERON	27
31073-067	SERVO CONTROL AIRLERON	27
31073-068	SERVO CONTROL AIRLERON	27
31073-110	SERVO CONTROL AIRLERON	27
31075-117	SERVO CONTROL ELEVATOR	27
31075-118	SERVO CONTROL ELEVATOR	27
31075-170	SERVO CONTROL ELEVATOR	27
31075-200	SERVO CONTROL ELEVATOR	27
31075-207	SERVO CONTROL ELEVATOR	27
31075-210	SERVO CONTROL ELEVATOR	27
31075-215	SERVO CONTROL ELEVATOR	27
31075-217	SERVO CONTROL ELEVATOR	27
31075-218	SERVO CONTROL ELEVATOR	27
31075-220	SERVO CONTROL ELEVATOR	27

31075-230	SERVO CONTROL ELEVATOR	27
31075-240	SERVO CONTROL ELEVATOR	27
31075-250	SERVO CONTROL ELEVATOR	27
31075-260	SERVO CONTROL ELEVATOR	27
31075-270	SERVO CONTROL ELEVATOR	27
31075-310	SERVO CONTROL ELEVATOR	27
31075-320	SERVO CONTROL ELEVATOR	27
31075-330	SERVO CONTROL ELEVATOR	27
31075-340	SERVO CONTROL ELEVATOR	27
31075-410	SERVO CONTROL ELEVATOR	27
31075-420	SERVO CONTROL ELEVATOR	27
31075-430	SERVO CONTROL ELEVATOR	27
31075-440	SERVO CONTROL ELEVATOR	27
31075-610	SERVO CONTROL ELEVATOR	27
31075-617	SERVO CONTROL ELEVATOR	27
31075-618	SERVO CONTROL ELEVATOR	27
31075-620	SERVO CONTROL ELEVATOR	27
31075-630	SERVO CONTROL ELEVATOR	27
31075-640	SERVO CONTROL ELEVATOR	27
31075-650	SERVO CONTROL ELEVATOR	27
31075-660	SERVO CONTROL ELEVATOR	27
31075-670	SERVO CONTROL ELEVATOR	27
31075-810	SERVO CONTROL ELEVATOR	27
31075-820	SERVO CONTROL ELEVATOR	27
31075-830	SERVO CONTROL ELEVATOR	27
31075-840	SERVO CONTROL ELEVATOR	27
31076-080	SERVO CONTROL SPOILER OUT	27
31077-050	SERVO CONTROL SPOILER INBD	27
31077-060	SERVO CONTROL SPOILER INBD	27
31077-070	SERVO CONTROL SPOILER INBD	27
31077-100	SERVO CONTROL SPOILER INBD	27

31077-110	SERVO CONTROL SPOILER INBD	27
31077-111	SERVO CONTROL SPOILER INBD	27
31077-112	SERVO CONTROL SPOILER INBD	27
31077-200	SERVO CONTROL SPOILER INBD	27
31077-211	SERVO CONTROL SPOILER INBD	27
310ZN01Y01	SENSOR CURRENT	29
3210005WB106	TRASH COMPACTOR	25
321000M02	SPEED BRAKE CTRL TRANSDUCER	27
321200M02	SPEED BRAKE CTRL TRANSDUCER	27
3214-30	BATTERY PACK	33
3214-31	BATTERY PACK	33
3214-52	EMERGENCY POWER SUPPLY UNIT	33
3214-54	EMERGENCY POWER SUPPLY UNIT	33
3214-54-10	EMERGENCY POWER SUPPLY UNIT	33
3214-54-20	EMERGENCY POWER SUPPLY UNIT	33
3214-55	EMERGENCY POWER SUPPLY UNIT	33
3214-55-10	EMERGENCY POWER SUPPLY UNIT	33
3214-62	EMERGENCY POWER SUPPLY UNIT	33
3214-62-10	EMERGENCY POWER SUPPLY UNIT	33
3214-62-20	EMERGENCY POWER SUPPLY UNIT	33
3217-100	VALVE RAIN REPELLENT	30
3217-200	VALVE RAIN REPELLENT	30
321-211-702-0	LEVER	78
322000M01	TRANSDUCER UNIT	32
322000M02	TRANSDUCER UNIT	32
322200-7M00	HANDWHEEL NOSE STEERING	32
322200-8M00	HANDWHEEL NOSE STEERING	32
324195-1	VALVE ANTI ICE	30
3250-80	BALLAST	33
3250-81	BALLAST	33
326975	NOSE COWL ANTI-ICE VALVE	30

327000-102M01	FTU-FORCE TRANSDUCER UNIT	27
327155-1	VALVE ANTI ICE	30
327155-2	VALVE ANTI ICE	30
327155-3	VALVE ANTI ICE	30
3282970-3	STOP MECHANISM BLEED VALVE	75
3282970-4	STOP MECHANISM BLEED VALVE	75
3282982-3	ACTUATOR TR OPENING	78
3290050-2	VALVE SURGE CONTROL	49
3290050-3	VALVE SURGE CONTROL	49
3290050-4	VALVE SURGE CONTROL	49
3290052-2	VALVE LOAD	49
3290052-3	VALVE LOAD	49
3290064-10	STARTER AIR VALVE	80
3290064-17	STARTER AIR VALVE	80
3290064-20	STARTER AIR VALVE	80
3290064-18	STARTER AIR VALVE	80
3290064-19	STARTER AIR VALVE	80
3290064-30	STARTER AIR VALVE	80
3291238-2	VALVE SURGE CONTROL	49
3291238-2	VALVE-SURGE CONTROL	49
3291432-1	VALVE-LOAD CONTROL	49
3291432-2	VALVE-LOAD CONTROL	49
3291556-1	STARTER AIR VALVE	80
3291556-2	STARTER AIR VALVE	80
3291556-3	STARTER AIR VALVE	80
32F0003	VALVE SCAVENGE	79
330400M01	CONTROL UNIT THROTTLE	76
330TS08Y	FIRE PANEL ENGINE APU	26
335TS08Y00	FIRE PANEL ENGINE APU	26
33600005-3	EXTINGUISHER FIRE APU	26
337-075-103-0	LUBRICATION UNIT	79

337-075-104-0	LUBRICATION UNIT	79
337-075-105-0	LUBRICATION UNIT	79
34100005-1	EXTINGUISHER FIRE ENGINE	26
341203-300	EYE END ASSY	27
341203-500	ROD END EQUIPPED	27
341E030000	THERMOSTAT SOLENOID	36
341F010000	THERMOSTAT SOLENOID	36
342300M00	TRANSDUCER UNIT	27
342300M01	TRANSDUCER UNIT	27
342B040000	THERMOSTAT CONTROL	36
342B050000	THERMOSTAT CONTROL	36
34600017	EXTINGUISHER CARGO	26
34600025-1	EXTINGUISHER CARGO	26
34600049-1	EXTINGUISHER FIRE	26
3505582-12	STARTER AIRTURBINE	80
3505582-14	STARTER AIRTURBINE	80
3505582-15	STARTER AIRTURBINE	80
3505582-26	STARTER AIRTURBINE	80
3505582-27	STARTER AIRTURBINE	80
3505582-43	STARTER AIRTURBINE	80
3505582-44	STARTER AIRTURBINE	80
3505582-45	STARTER AIRTURBINE	80
3505582-60	STARTER AIRTURBINE	80
3505582-61	STARTER AIRTURBINE	80
3505582-62	STARTER AIRTURBINE	80
3505582-63	STARTER AIRTURBINE	80
3505582-64	STARTER AIRTURBINE	80
3505582-65	STARTER AIRTURBINE	80
35-0D5-1002	LOUDSPEAKER AMPLIFIER COCKPIT	31
35-0D5-1003	LOUDSPEAKER AMPLIFIER COCKPIT	31
350E017248685	COMPUTER FLIGHT WARNING	31

350E017251414	COMPUTER FLIGHT WARNING	31
350E017271616	COMPUTER FLIGHT WARNING	31
350E018312020	COMPUTER FLIGHT WARNING	31
350E051020101	COMPUTER FLIGHT WARNING	31
350E052020202	COMPUTER FLIGHT WARNING	31
350E052020303	COMPUTER FLIGHT WARNING	31
350E053020707	COMPUTER FLIGHT WARNING	31
350E053020909	COMPUTER FLIGHT WARNING	31
350E053021010	COMPUTER FLIGHT WARNING	31
350E053021111	COMPUTER FLIGHT WARNING	31
350E053021212	COMPUTER FLIGHT WARNING	31
350E053021414	COMPUTER FLIGHT WARNING	31
350E053021515	COMPUTER FLIGHT WARNING	31
350E053021616	COMPUTER FLIGHT WARNING	31
350E053021717	COMPUTER FLIGHT WARNING	31
350E053021818	COMPUTER FLIGHT WARNING	31
350E053021919	COMPUTER FLIGHT WARNING	31
350E5151022	SDAC - SYSTEM DATA AQUISITION CONCENTRATOR	31
350E5151331	SDAC - SYSTEM DATA AQUISITION CONCENTRATOR	31
350E5161122	SDAC - SYSTEM DATA AQUISITION CONCENTRATOR	31
350E053020909	FWC - FLIGHT WARNING COMPUTER	31
350E053021212	FWC - FLIGHT WARNING COMPUTER	31
350E053021818	FWC - FLIGHT WARNING COMPUTER	31
350E5500202	SDAC - SYSTEM DATA AQUISITION CONCENTRATOR	31
350E5500204	SDAC - SYSTEM DATA AQUISITION CONCENTRATOR	31
350E5500205	SDAC - SYSTEM DATA AQUISITION CONCENTRATOR	31
350E5500206	SDAC - SYSTEM DATA AQUISITION CONCENTRATOR	31
35-0F5-1000	BOARD ANNUNCIATOR LIGHT	33
35-0F6-1001	ANNUNCIATOR LIGHT	33
35-0L0-1001-04	ECAM CTRL PANEL	31
35-0L0-1002-05	ECAM CTRL PANEL	31

35-0L0-1003-06	ECAM CTRL PANEL	31
35-0L5-1005-08	BATTERY CHARGE LIMITER	24
35-0L5-1006-08	BATTERY CHARGE LIMITER	24
35-0L5-1107-08	BATTERY CHARGE LIMITER	24
350880-6	ENGINE DRIVEN PUMP	29
350880-7	ENGINE DRIVEN PUMP	29
35-1H5-1001	BRAKE TEMP MONITORING	32
35-1H5-1002	BRAKE TEMP MONITORING	32
3510-0044-05	COFFEE MAKER	25
3552AAADAACXCD	OXYGEN CYLINDER ASSY	35
3552AAAWAACXCD	OXYGEN CYLINDER ASSY	35
3552AAAXAACXCD	OXYGEN CYLINDER ASSY	35
3601-91	DETECTOR FIRE	26
367-359-004	ICU - IGGS CONTROLLER UNIT	47
367-359-004	ICU - IGGS CONTROLLER UNIT	47
3720-00-00	FDU - FIRE DETECTION UNIT	26
3720-01-01	FDU - FIRE DETECTION UNIT	26
3721-00	FDU - FIRE DETECTION UNIT	26
3732A010000	EXCHANGER PRECOOLER	36
3800278-4	APU - AUXILIARY POWER UNIT	49
3800708-1	APU - AUXILIARY POWER UNIT	49
3830416-1	NOZZLE FUEL	49
3860864-1	CLUTCH ASSY STARTER	49
3862775-1	FAN ASSY	49
3862775-2	FAN ASSY	49
3862775-3	FAN ASSY	49
3876124-1	THERMOCOUPLE IMMERSION	49
3876125-5	SWITCH OIL LOW PRESSURE	49
3876126-3	SWITCH OIL HIGHT TEMP	49
3876128-2	SWITCH OIL LEVEL	49
3876130-3	SENSOR TEMP INLET	49

3876134-1	SENSOR PRESSURE TOTAL	49
3876135-1	SENSOR PRESSURE TOTAL	49
3876144-1	SENSOR OIL TEMP	49
3876226-1	SENSOR PRESSURE TEMP	49
3876255-2	SENSOR PRESSURE TEMP	49
3880190-11	PUMP LUBE ASSY	49
3880190-13	PUMP LUBE ASSY	49
3880650-8	PUMP SCAVENGE	49
3882825-6	FCU APU - FUEL CONTROL UNIT APU	49
3882825-8	FCU APU - FUEL CONTROL UNIT APU	49
3882825-9	FCU APU - FUEL CONTROL UNIT APU	49
3882835-3	DIVIDER FLOW	49
3882835-4	DIVIDER FLOW	49
3882835-4-1	DIVIDER FLOW	49
3884581-1	SENSOR	49
3884581-2	SENSOR	49
3886188-3	ACTUATOR-IGV	49
3886188-3	ACTUATOR-IGV	49
3888058-5	EXICITER IGNITION ETOPS	49
3888058-7	EXICITER IGNITION ETOPS	49
3888394-120201	ELECTRONIC CONTROL BOX - APU	49
3888394-121202	ELECTRONIC CONTROL BOX - APU	49
3888394-221202	ELECTRONIC CONTROL BOX - APU	49
3888394-221203	ELECTRONIC CONTROL BOX - APU	49
3888394-221203	ECB-ELECTRONIC CONTROL BOX	49
3888394-221204	ECB-ELECTRONIC CONTROL BOX	49
3888394-221205	ECB-ELECTRONIC CONTROL BOX	49
3888394-310104	ECB-ELECTRONIC CONTROL BOX	49
3888394-321206	ECB-ELECTRONIC CONTROL BOX	49
38E93-4	VALVE ANTI ICE	30
38E93-5	VALVE ANTI ICE	30

38E93-6	VALVE ANTI ICE	30
3945129100	ELAC-ELEVATOR AILERON COM	27
3957985205	EIU-ENGINE INTERFACE UNIT	73
3957985206	EIU-ENGINE INTERFACE UNIT	73
3957A0000-02	VALVE ISOLATION	21
3958A0000-01	VALVE BYPASS	21
3959A0000K05	CONTROLLER CSAS	21
3959A0000K06	CONTROLLER CSAS	21
3962A0000K01	CONVERTER OZONE	21
3964A0000K01	SENSOR TEMPERATURE	21
398-21	FILTER	36
401MFD1-1	DCDU - DATALINK CONTROL DISPLAY UNIT	46
401MFD2-1	DCDU - DATALINK CONTROL DISPLAY UNIT	46
401MFD3-2	DCDU - DATALINK CONTROL DISPLAY UNIT	46
401MFD3-3	DCDU - DATALINK CONTROL DISPLAY UNIT	46
400SV01Y01	SLEEVE PUSH BUTTON SWITCH	24
4055500-906	MCDU - MULTIFUNCTION CONTROL DISPLAY UNIT	22
4055500-907	MCDU - MULTIFUNCTION CONTROL DISPLAY UNIT	22
4077880-961	MCDU - MULTIFUNCTION CONTROL DISPLAY UNIT	22
4089740-960	MCDU - MULTIPURPOSE CONTROL	22
4089740-961	MCDU - MULTIPURPOSE CONTROL	22
4101002-11	PTU - POWER TRANSFERT UNIT	29
4101002-7	PTU - POWER TRANSFERT UNIT	29
4101002-8	PTU - POWER TRANSFERT UNIT	29
4101002-9	PTU - POWER TRANSFERT UNIT	29
4101002-11	PTU - POWER TRANSFERT UNIT	29
4101002-13	PTU - POWER TRANSFERT UNIT	29
41-2-1100	ACTUATOR EMERGENCY RAM	21
41-2-1100-01	ACTUATOR EMERGENCY RAM	21
41-2-1100-02	ACTUATOR EMERGENCY RAM	21
4131020-4	MODULE LUBE	49

4141028-3	VALVE DE OIL SOLENOID	49
416-0001-9	COFFEE MAKER	25
416-0001-29	COFFEE MAKER	25
416-00318-003	COMPUTER WINDOW HEAT	30
4188-00	INVERTER STATIC	24
4188-01	INVERTER STATIC	24
4191695	RETRACTABLE LANDING LIGHT	33
41F1004	UNIT LUB	79
41F1005	UNIT LUB	79
41SG240-1	TRANSMITTER OIL PRESS DIF	29
41SG240-4	TRANSMITTER OIL PRESS DIF	29
41SG272-5	TRANSDUCER PRESSURE	29
41SG272-6	TRANSDUCER PRESSURE	29
4203503	MOTOR HYDRAULIC SLAT&FLAP	27
4203504	MOTOR HYDRAULIC SLAT&FLAP	27
42049	MOTOR HYDRAULIC THSA	27
4205400	PUMP HYDRAULIC	29
4205401	PUMP HYDRAULIC	29
421924-200	MOTOR HYDRAULIC THSA	27
421924-300	MOTOR HYDRAULIC THSA	27
422799-400	MODULE ELECTRONIC	27
422799-500	MODULE ELECTRONIC	27
4233488	LIGHT TAKE OFF	33
4236534	LIGHT RUNWAY TURNOFF	33
4236564	LIGHT TAXI	33
4260-10-02	LIGHT CARGO COMPARTMENT	33
4279198	MOTOR CONVERTER	30
4279204	MOTOR CONVERTER	30
430153	GENERATOR STATOR	73
430201	GENERATOR STATOR	73

430201-1	GENERATOR STATOR	73
43-1-1100	ACTUATOR APU INLET DOOR	49
4313100-01-6600	OVEN	25
4315542	LIGHT RETRACTABLE LANDING	33
4323100-00-6622	OVEN STEAMER	25
4323100-01-6622	OVEN STEAMER	25
4323101-00-6622	OVEN STEAMER	25
4331772	LIGHT RETRACTABLE LANDING	33
4357619	ARM WIPER	30
4357626	ARM WIPER	30
4360004-88-0018	WATER HEATER	25
4360004-88-00-18	WATER HEATER	25
441921-4	FCU APU - FUEL CONTROL UNIT	49
441921-5	FCU APU - FUEL CONTROL UNIT	49
442920-1	MANIFOLD DISTRIBUTION	35
4506013	DRAIN VALVE	49
4510-22LG-00	COFFEE MAKER	25
45332-8036	HEAT EXCHANGER OIL FUEL MAIN	79
45332-8039	HEAT EXCHANGER OIL FUEL MAIN	79
45731-1381	HEATER SERVO FUEL	73
45731-1382	HEATER SERVO FUEL	73
45731-1391	COOLER IDG OIL	73
45731-1392	COOLER IDG OIL	73
45731-1393	COOLER IDG OIL	73
45D31	SWITCH DIFFERENTIAL PRESSURE	73
45D31-2	SWITCH DIFFERENTIAL PRESSURE	73
45D32	SWITCH LOW OIL PRESSURE	79
45D34	SWITCH LOW OIL PRESSURE	79
46012	MOTOR HYDRAULIC THSA	27
465020-0303-0312	ADIRU - AIR DATA INERTIAL REFERENCE UNIT	34

466-8	SENSOR TEMPERATURE	
4678-700-80-10	INDICATOR ANGLE OF ATTACK	34
47145-021	ACTUATOR THS	27
47145-030	ACTUATOR THS	27
47145-031	ACTUATOR THS	27
47145-032	ACTUATOR THS	27
47145-033	ACTUATOR THS	27
47145-034	ACTUATOR THS	27
47145-035	ACTUATOR THS	27
47145-036	ACTUATOR THS	27
47145-037	ACTUATOR THS	27
47145-121	ACTUATOR THS	27
47145-130	ACTUATOR THS	27
47145-131	ACTUATOR THS	27
47145-132	ACTUATOR THS	27
47145-133	ACTUATOR THS	27
47145-134	ACTUATOR THS	27
47145-135	ACTUATOR THS	27
47145-136	ACTUATOR THS	27
47145-137	ACTUATOR THS	27
47145-140	ACTUATOR THS	27
47145-141	ACTUATOR THS	27
47145-142	ACTUATOR THS	27
47145-143	ACTUATOR THS	27
47145-144	ACTUATOR THS	27
47145-145	ACTUATOR THS	27
47145-146	ACTUATOR THS	27
47145-147	ACTUATOR THS	27
47145-166	ACTUATOR THS	27
47145-167	ACTUATOR THS	27

47145-267	ACTUATOR THS	27
47145-268	ACTUATOR THS	27
47147-710	ACTUATOR THS	27
472088-1	EXTINGUISHER	26
472088-2	EXTINGUISHER	26
47215920BB00	COMPUTER PROBE HEAT	30
49-117-10	COMPUTER SFCC	27
49-170-07	COMPUTER SFCC	27
49-170-11	COMPUTER SFCC	27
4A7033	FILTER-SCAVENGE OIL	79
4A7033B	FILTER-SCAVENGE OIL	79
4A7043	COVER ASSY	79
4A7081	VALVE ASSY	79
4A7110	PUMP & FILTER ASSY	79
4A7110B	PUMP & FILTER ASSY	79
4A7118	SCAVENGE PUMP ASSY	79
4A7121	SCAVENGE PUMP ASSY	79
4A7124	SCAVENGE PUMP ASSY	79
4A7124A	SCAVENGE PUMP ASSY	79
5000C5029	ELECTRICAL LOAD SENSING	27
50069001-1	COOLER OIL AIR	79
5009913E	PUMP FUEL	73
5009913G	PUMP FUEL	73
503CA02F1-02Y1	CONTACTOR THREE POLE	24
503CA04F2-02Y00	CONTACTOR THREE POLE	24
51154-04	PUMP ELECTRIC	29
520550	HYDRAULIC PUMP RAT	29
520912	CSMG - CONSTANT SPEED MOTOR GENERATOR	24
520913	CSMG - CONSTANT SPEED MOTOR GENERATOR	24
520915	GCU - GENERATOR CONTROL UNIT	24
521100	GCU - GENERATOR CONTROL UNIT	24

521B0200-01	ADAPTER ASSY-PPU	27
528-70	LIGHT NAVIGATION GREEN	33
5500-A1A-BF20B	PORTABLE OXYGEN CYLINDER ASSY	35
5500-A1A-BF23A	PORTABLE OXYGEN CYLINDER ASSY	35
5500-A1A-BF23B	PORTABLE OXYGEN CYLINDER ASSY	35
5500-B1A-BF23A	PORTABLE OXYGEN CYLINDER ASSY	35
5500-C1A-BF20B	PORTABLE OXYGEN CYLINDER ASSY	35
5500-C1A-BF23A	PORTABLE OXYGEN CYLINDER ASSY	35
5500-C1A-BF23B	PORTABLE OXYGEN CYLINDER ASSY	35
5500-C6A-F20AR	PORTABLE OXYGEN CYLINDER ASSY	35
55022001-11	COOLER OIL	79
5507-910-0	CHIP DETECTOR	79
558CA01Y1	CONTACTOR THREE POLE	24
558CA04A30Y00	CONTACTOR THREE POLE	24
558CA04A40Y00	CONTACTOR THREE POLE	24
564CA01Y1	CONTACTOR THREE POLE	24
564CA04A01Y00	CONTACTOR THREE POLE	24
564CA04A10Y00	CONTACTOR THREE POLE	24
564CA04A11Y00	CONTACTOR THREE POLE	24
564CA04A20Y00	CONTACTOR THREE POLE	24
564CA04A21Y00	CONTACTOR THREE POLE	24
564CA04F10Y00	CONTACTOR THREE POLE	24
564CA04F20Y00	CONTACTOR THREE POLE	24
568-1-27202-002	PUMP FUEL	28
568-1-27202-02R	PUMP FUEL	28
568-1-27202-005	PUMP FUEL	28
568-1-27202-05R	PUMP FUEL	28
568-1-27202-006	PUMP FUEL	28
568-1-27202-007	PUMP FUEL	28
568-1-27203-002	CANISTER FUEL PUMP	28
568-1-27203-003	CANISTER FUEL PUMP	28

568-1-27244-002	CANISTER FUEL PUMP	28
568-1-27244-003	CANISTER FUEL PUMP	28
5822-21	POWER SUPPLY FLOOR LIGHT	33
5860010-108	VALVE AIR STAGE 10 HP	75
5860016-139	ACTUATOR VALVE	75
5860017-139	ACTUATOR VALVE	75
5860017-144	ACTUATOR VALVE	75
5913667-3	GENERATOR APU	49
5913667-4	GENERATOR APU	49
59880	INDICATOR PRESSURE	49
5L0039	ACTUATOR SLAVE	75
5L0040	COOLER IDG OIL	74
5U0072	IGNITION LEAD	74
5XA005032-01	CONTROLLER LIGHTING	33
5XA005033-00	CONTROLLER LIGHTING	33
5XA455805-01	CONTROLLER LIGHTING	33
5XA455806-00	CONTROLLER LIGHTING	33
600611-00-506	CONTROLLER HEAT	21
600611-00-600	CONTROLLER HEAT	21
600611-00-601	CONTROLLER HEAT	21
600615-00-502	CONTROLLER VENT - CARGO	21
600615-00-503	CONTROLLER VENT - CARGO	21
600629-00-500	CONTROL BOX	25
60592-101	RESERVOIR - ESCAPE SLIDE	25
60592-103	RESERVOIR - ESCAPE SLIDE	25
60592-201	RESERVOIR - ESCAPE SLIDE	25
60592-203	RESERVOIR - ESCAPE SLIDE	25
607690-2	TRANSMITTER EMERGENCY LOCATOR	25
607690-5	TRANSMITTER EMERGENCY LOCATOR	25
6137-3	RUDDER TRIM ACTUATOR	27
6137-4	RUDDER TRIM ACTUATOR	27

6137-5	RUDDER TRIM ACTUATOR	27
6-1404-0000-4	PUMP HAND HYDRAULIC	32
615-2630-102	ANTENNA-ADF	34
61639-103	RESERVOIR ASSY	25
61639-203	RESERVOIR ASSY	25
617-6231-001	MONITOR LCD LH	23
617-6231-013	MONITOR LCD	23
617-6231-014	MONITOR LCD	23
6207-88-62	ANTENNA LOCALIZER	34
62197-001-001	WATER BOILER	25
62197-001-001	WATER BOILER	25
62197-101-001	WATER BOILER	25
62198-001-001	WATER BOILER	25
622-4540-023	TRANSCEIVER NAV-DME	34
622-4542-020	TRANSCEIVER RADIO ALTIMETER	34
622-5001-504	INDICATOR RDM	34
622-5129-020	CONTROLLER WEATHER RADAR	34
622-5130-020	CONTROLLER WEATHER RADAR	34
622-5130-021	CONTROLLER WEATHER RADAR	34
622-5130-820	CONTROLLER WEATHER RADAR	34
622-5132-120	TRANSCEIVER WEATHER RADAR	34
622-5132-622	TRANSCEIVER WEATHER RADAR	34
622-5132-623	TRANSCEIVER WEATHER RADAR	34
622-5132-624	RECEIVER TRANSMITTER	34
622-5134-064	TRAY-MOUNTING.WR XCVR	34
622-5136-001	MOUNT WEATHER RADAR	34
622-5136-201	MOUNT WEATHER RADAR	34
622-5136-801	MOUNT WEATHER RADAR	34
622-5137-601	ANTENNA WEATHER RADAR	34
622-5220-020	RECEIVER VOR/MARKER	34
622-5222-020	RECEIVER ADF	34

622-5272-020	TRANSCEIVER HF	23
622-5272-023	TRANSCEIVER HF	23
622-7878-301	TRANSPONDER ATC	34
622-8971-322	COMPUTER TCAS	34
622-8701-004	ANTENNA RADIO ALTIMETER	34
622-8973-104	ANTENNA TCAS	34
622-9738-020	RECEIVER ILS	34
622-9738-040	RECEIVER ILS	34
622-9738-041	RECEIVER ILS	34
62292-107	SLIDE DOOR 2	25
62292-108	SLIDE DOOR 2	25
62292-109	SLIDE DOOR 2	25
62292-110	SLIDE DOOR 2	25
62293-107	SLIDE DOOR 3	25
62293-108	SLIDE DOOR 3	25
62293-109	SLIDE DOOR 3	25
62293-110	SLIDE DOOR 3	25
623977	HYDRAULIC PUMP	29
630CC01Y1	CONTACTOR SINGLE POLE	24
630CC04A0Y00	CONTACTOR SINGLE POLE	24
630CC04A1Y00	CONTACTOR SINGLE POLE	24
630CC04A2Y00	CONTACTOR SINGLE POLE	24
6331-16639-5	ELECTRONIC BOX	21
63540-041-2	INDICATOR RMI-ADF	34
63543-150-2	INDICATOR RMI	34
63543-150-3	INDICATOR RMI	34
63543-150-4	INDICATOR RMI	34
63543-150-5	INDICATOR RMI	34
63543-250-3	INDICATOR VOR-DME	34
63543-250-4	INDICATOR VOR-DME	34
64050-866-1	INDICATOR AIRSPEED	34

640CC01Y1	CONTACTOR SINGLE POLE	24
640CC04A2Y00	CONTACTOR SINGLE POLE	24
64141-580-1	ALTIMETER STANDBY	34
642-1000-501	COWL ASSY AIR INLET	71
642-1000-505	COWL ASSY AIR INLET	71
642-1004-501	TUBE ANTI-ICE SUPPLY	71
642-1004-503	TUBE ANTI-ICE SUPPLY	71
642-1016-501	DUCT ANTI ICE EXHAUST	30
642-1017-503	BOOT ASSY ANTI ICE	30
642-1026-501	DOOR ASSY PRESSURE RELIEF	71
642-1026-503	DOOR ASSY PRESSURE RELIEF	71
642-3001-503	COWL ASSY LH	71
642-3001-505	FAN COWL LH	71
642-3001-507	FAN COWL LH	71
642-3001-509	FAN COWL LH	71
642-3002-501	COWL ASSY FAN RH	71
642-3002-503	COWL ASSY FAN RH	71
642-3002-505	COWL ASSY FAN RH	71
642-3002-511	COWL ASSY FAN	71
642-3002-515	COWL ASSY FAN	71
642-3801-507	THRUST REVERSER LH	78
642-3801-509	THRUST REVERSER LH	78
642-3801-511	THRUST REVERSER LH	78
642-3801-515	THRUST REVERSER LH	78
642-3801-519	THRUST REVERSER LH	78
642-3801-521	THRUST REVERSER LH	78
642-3801-525	THRUST REVERSER LH	78
642-3801-527	DOOR ASSY FAN	78
642-3801-529	THRUST REVERSER LH	78
642-3801-533	DOOR ASSY FAN	78

642-3802-507	THRUST REVERSER RH	78
642-3802-509	THRUST REVERSER RH	78
642-3802-511	THRUST REVERSER RH	78
642-3802-513	THRUST REVERSER RH	78
642-3802-517	THRUST REVERSER RH	78
642-3802-521	THRUST REVERSER RH	78
642-3802-523	THRUST REVERSER RH	78
642-3802-527	THRUST REVERSER RH	78
642-3802-529	DOOR ASSY FAN	78
642-3802-531	THRUST REVERSER RH	78
64300-210	BOOMSET	23
64882-206-1	INDICATOR BRAKE PRESSURE	32
65566-1	VALVE REGULATOR ASSY	25
655CC01Y2	CONTACTOR	24
655CC04A0Y00	CONTACTOR	24
6610-15945	ACTUATOR ROTARY	21
6610-19878-2	ACTUATOR ROTARY	21
6610-20560-01	ACTUATOR ROTARY	21
6610-20567-01	ACTUATOR ROTARY	21
664700500A4C	LGCIU - LANDING GEAR CONTROL INTERFACE UNIT	32
664700500A4D	LGCIU - LANDING GEAR CONTROL INTERFACE UNIT	32
6664202-2	COMPUTER HEAT - WINDOW	30
6664202-3	COMPUTER HEAT - WINDOW	30
6664202-4	COMPUTER HEAT - WINDOW	30
6664287-0	COMPUTER HEAT - WINDOW	30
6714D010000	VALVE BLEED PRESSURE	36
6714D020000	VALVE BLEED PRESSURE	36
6714D040000	VALVE BLEED PRESSURE	36
6714D060000	VALVE BLEED PRESSURE	36
6714D060000A	VALVE BLEED PRESSURE	36
6714D070000	VALVE BLEED PRESSURE	36

6730B01	VALVE FAN AIR	36
6730C010000	VALVE FAN AIR	36
6730F010000	VALVE FAN AIR	36
6740B050000	VALVE OVERPRESSURE	36
6740E010000	VALVE OVERPRESSURE	36
6740F010000	VALVE OVERPRESSURE	36
6740G010000	VALVE OVERPRESSURE	36
6774B020000	VALVE BLEED PRESSURE	36
6774B030000	VALVE BLEED PRESSURE	36
6774E010000	VALVE BLEED PRESSURE	36
6774G010000	VALVE BLEED PRESSURE	36
692546-4	VALVE-SOLENOID	49
693335	PUMP MOTOR DRIVEN	29
6A8281	HARNESS	71
7S610412	CONTAINER	25
7012-18088	VALVE SAFETY	21
7012-18088-03	VALVE SAFETY	21
70227A010001	CONVERTER OZONE	21
70853A010001	VALVE TRIM AIR PRESSURE	21
7110-36-0000	OVEN CONTROL BOX	25
7110-36-0000A	OVEN CONTROL BOX	25
700TS06Y111	FIRE PANEL ENGINE APU	26
700TS06Y12	FIRE PANEL ENGINE APU	26
710TS06Y01	TRANSMITTER	32
710TS06Y11	TRANSMITTER	32
711TS06Y	TRANSMITTER	32
715TS06Y11	TRANSMITTER	32
716TS06Y11	TRANSMITTER	32
72E03-1	FILTER PILOT VALVE	30
72303102-4	LIGHT NAVIGATION GREEN	33
72303102-6	LIGHT NAVIGATION GREEN	33

72303102-8	LIGHT NAVIGATION GREEN	33
72324693-4	LED MODULE	33
727-1154-02	LIGHT NAVIGATION GREEN	33
727-1155-02	LIGHT NAVIGATION RED	33
727-1213-01	LIGHT LANDING	33
727-1213-02	LIGHT LANDING	33
727-1313-02	LIGHT MAIN INSTRUMENT PAN	33
727-1314-02	FLOODLIGHT UNIT CAPTAIN	33
727-1315-02	FLOODLIGHT UNIT FIRST OFFICER	33
727-1320-02	CONTROLLER LIGHTING	33
727-1321-02	CONTROLLER LIGHTING	33
73195	SERVOVALVE AILERON	27
733901-1-1	BMC - BLEED MONITORING COMP	36
733901-1-2	BMC - BLEED MONITORING COMP	36
733902-1-2	PHC - PROBE HEAT COMPUTER	30
740120A	GCU - GENERATOR CONTROL UNIT	24
740120B	GCU - GENERATOR CONTROL UNIT	24
740120C	GCU - GENERATOR CONTROL UNIT	24
740121A	GPCU - GROUND POWER CONTROL UNIT	24
740121B	GPCU - GROUND POWER CONTROL UNIT	24
740-0052-501	LINK	78
740-3000-593	COWL AIR INTAKE	71
740-3000-601	COWL AIR INTAKE	71
740-5862-507	HARNESS FIRE DETECTION	71
740-5869-507	CABLE	24
740-5966-525	HARNESS GENERAL SERVICE	71
740-5966-529	HARNESS GENERAL SERVICE	71
740D8003-13	DRIVE UNIT	78
740D8003-27	CONTROL UNIT	78
740D8003-31	ACTUATOR LOCKING	78

740D8003-32	ACTUATOR NON LOCKING	78
740D8003-42	ACTUATOR NON LOCKING	78
740D8007-5	ACTUATOR LOCKING	78
743-0215-030	SYSTEM CONTROL UNIT	23
743-0238-001	VIDEO TAPE REPRODUCER	23
743-0304-001	VIDEO TAPE REPRODUCER	23
745-3000-503	COWL AIR INTAKE	71
745-3000-505	INLET NOSE COWL	71
745-3000-507	COWL AIR INTAKE	71
745-3000-513	COWL AIR INTAKE	71
745-3000-9511	COWL AIR INTAKE	71
745-3400-501	COWL AIR INTAKE	71
745-3400-503	COWL AIR INTAKE	71
745-3400-507	COWL AIR INTAKE	71
745-5870-503	HARNESS EEC SUPPLY	71
745-5967-515	HARNESS	71
745-5967-517	HARNESS	71
746923E	EGIU - ELECTRICAL GENERATION INTERFACE UNIT	24
746A0000-04	VALVE REGULATING PRESSURE	21
746A0000-05	VALVE REGULATING PRESSURE	21
746A0000-06	VALVE REGULATING PRESSURE	21
747A0000-03	EXTRACTOR WATER	21
747C0000-01	EXTRACTOR WATER	21
749A0000-02	CHAMBER PLENUM	21
750A0000-02	VALVE TRIM PRESSURE AIR	21
750B0000-01	VALVE CONTROL FLOW	21
751A0000-05	VALVE CONTROL FLOW	21
751A0000-07	VALVE CONTROL FLOW	21
751B0000-02	VALVE CONTROL FLOW	21
751F0000-01	VALVE CONTROL FLOW	21
751G0000-01	VALVE CONTROL FLOW	21

753A0000-03	EXCHANGER HEAT	21
753A0000-04	EXCHANGER HEAT - PRIMARY	21
753B0000-02	EXCHANGER HEAT - PRIMARY	21
753B0000-03	EXCHANGER HEAT - PRIMARY	21
753C0000-01	EXCHANGER HEAT - PRIMARY	21
753C0000-02	EXCHANGER HEAT - PRIMARY	21
754A0000-03	EXCHANGER HEAT - MAIN	21
754B0000-02	EXCHANGER HEAT - MAIN	21
754C0000-01	EXCHANGER HEAT - MAIN	21
754D0000-01	EXCHANGER HEAT - MAIN	21
755A0000-01	REHEATER	21
755A0000-03	REHEATER	21
755A0000-04	REHEATER	21
755B0000-02	REHEATER	21
755C0000-01	REHEATER	21
756669C	SHAFT ASSY	49
756722A	VALVE-DE OILING	49
756722B	VALVE-DE OILING	49
756A0000-05	CONDENSER	21
756A0000-06	CONDENSER	21
757A0000-08	AIR CYCLE MACHINE	21
757A0000-09	AIR CYCLE MACHINE	21
757A0000-10	AIR CYCLE MACHINE	21
757C0000-02	AIR CYCLE MACHINE	21
757T0000-02	AIR CYCLE MACHINE	21
758A0000-02	VALVE BYPASS	21
759A0000-10	CONTROLLER PACK	21
759C0000-02	CONTROLLER PACK	21
759D0000-01	CONTROLLER PACK	21
759D0000-02	CONTROLLER PACK	21
761A0000-03	ACTUATOR RAM AIR	21
761A0000-04	ACTUATOR RAM AIR	21

761B0000-01	ACTUATOR RAM AIR	21
76-167-10	TRANSMITTER OIL QTY	79
762080-1	VALVE SAFETY	32
762080-1A	VALVE SAFETY	32
762308A	RAM AIR TURBINE	29
762308B	RAM AIR TURBINE	29
762308C	RAM AIR TURBINE	29
762A0000-03	ACTUATOR RAM AIR	21
762A0000-04	ACTUATOR RAM AIR	21
763A0000-02	SELECTOR TEMPERATURE	21
763A0000-04	ACTUATOR RAM AIR	21
764A0000-03	SELECTOR TEMPERATURE	21
764B0000-01	SELECTOR TEMPERATURE	21
764B0000-02	SELECTOR TEMPERATURE	21
766A0000-01	SELECTOR TEMPERATURE	21
766352A	RAM AIR TURBINE	29
766352B	RAM AIR TURBINE	29
767584H	GCU - GENERATOR CONTROL UNIT	24
767584J	GCU - GENERATOR CONTROL UNIT	24
767584K	GCU - GENERATOR CONTROL UNIT	24
767584L	GCU - GENERATOR CONTROL UNIT	24
767584M	GCU - GENERATOR CONTROL UNIT	24
768A0000-03	SENSOR PRESSURE	21
769105A	RGM - RAT GROUND MODULE	29
769106A	RGM - RAT GROUND MODULE	29
769A0000-01	VALVE CHECK	21
769A0000-02	VALVE CHECK	21
769B0000-01	VALVE CHECK	21
7702-04	DETECTOR	26
772292	IDG-INTEGRATED DRIVE GENE	24
773A0000-01	SENSOR TEMPERATURE	21

775A0000-07	CONTROLLER ZONE	21
775A0000-08	CONTROLLER ZONE	21
775C0000-04	CONTROLLER ZONE	21
775D0000-01	CONTROLLER ZONE	21
777B0000-02	SELECTOR TEMPERATURE	21
780A0000-01	SENSOR	27
780A0000-02	SENSOR	27
780B0000-01	SENSOR	27
785-002-61	BMC - BLEED MONITORING COMPUTER	28
785-002-68	BMC - BLEED MONITORING COMPUTER	28
785-002-7	BMC - BLEED MONITORING COMPUTER	28
785-002-8	BMC - BLEED MONITORING COMPUTER	28
785-002-9	BMC - BLEED MONITORING COMPUTER	28
786A0000-12	CONTROL UNIT POWER	27
786A0000-13	CONTROL UNIT POWER	27
786A1900-01	BRAKE-PRESSURE-OFF	27
786A2000-01	BRAKE-PRESSURE-OFF	27
787A0000-04	BLOCK VALVE	27
787A0000-07	BLOCK VALVE	27
787A0000-08	BLOCK VALVE	27
788A0000-01	GEARBOX-RIGHT ANGLE	27
788A0000-02	GEARBOX-RIGHT ANGLE	27
789A0000-01	GEARBOX-LINE	27
789A0000-02	GEARBOX-LINE	27
790424-4	VALVE STARTER PNEUMATIC	80
790425A6	STARTER PNEUMATIC	80
790425A8	STARTER PNEUMATIC	80
790425A9	STARTER PNEUMATIC	80
790A0000-01	GEARBOX	27
790A0000-02	GEARBOX	27
791A0000-02	ACTUATOR FLAP N1	27

791A0000-03	ACTUATOR FLAP N1	27
791A0000-04	ACTUATOR FLAP N1	27
791A0000-05	ACTUATOR FLAP N1	27
791A0000-06	ACTUATOR FLAP N1	27
791C0000-01	ACTUATOR FLAP N1	27
791C0000-02	ACTUATOR FLAP N1	27
792-6140-001	HF ANTENNA COUPLER	23
792A0000-03	ACTUATOR FLAP N2	27
792A0000-04	ACTUATOR FLAP N2	27
792A0000-05	ACTUATOR FLAP N2	27
792A0000-06	ACTUATOR FLAP N2	27
792A0000-07	ACTUATOR FLAP N2	27
792D0000-01	ACTUATOR-FLAP NO. 2	27
792D0000-02	ACTUATOR-FLAP NO. 2	27
792E0000-01	ACTUATOR-FLAP NO. 2	27
793A0000-03	ACTUATOR FLAP N3	27
793A0000-04	ACTUATOR FLAP N3	27
793A0000-05	ACTUATOR FLAP N3	27
793A0000-06	ACTUATOR FLAP N3	27
793A0000-07	ACTUATOR FLAP N3	27
793C0000-01	ACTUATOR FLAP N3	27
794A0000-02	ACTUATOR FLAP N3	27
794A0000-03	ACTUATOR FLAP N4	27
794A0000-04	ACTUATOR FLAP N4	27
794A0000-05	ACTUATOR FLAP N4	27
794A0000-06	ACTUATOR FLAP N4	27
794C0000-01	ACTUATOR FLAP N4	27
794C0000-02	ACTUATOR FLAP N4	27
794D0000-01	ACTUATOR-FLAP NO. 4	27
795020-12-021	DATA MANAGEMENT UNIT	31
795020-12-022	DATA MANAGEMENT UNIT	31

795030-10-001	DATA MANAGEMENT UNIT	31
796050-1	VALVE-FUEL DISTRIBUTION	73
796-809-5	SENSOR CADENSICON	28
796-809-6	SENSOR CADENSICON	28
796-809-6A	SENSOR CADENSICON	28
796-815-01-02	PRESELECTOR	28
796815-02-03	PRESELECTOR	28
796-815-02-03	PRESELECTOR	28
796-815C1-01	PRESELECTOR	28
8000281Y00	LIGHT RUNWAY TURNOFF	33
8000282Y00	LIGHT TAXI	33
8000283Y00	LIGHT TAKE OFF	33
8000306Y00	LIGHT RUNWAY TURNOFF	33
8000959Y00	LIGHT WING AND ENGINE LH	33
8000960Y00	LIGHT WING AND ENGINE RH	33
8001-06-0000	OVEN	25
8001-26-0000A	OVEN	25
801307-00	OXYGEN CYLINDER & VALVE ASSY	35
801A0200-01	SHAFT DRIVE AND PLUNGING	27
801A0300-01	SHAFT DRIVE AND PLUNGING	27
801A3400-01	JOINT ASSY	27
801A3500-01	JOINT ASSY	27
801B0200-01	SHAFT DRIVE AND PLUNGING	27
801B0300-01	SHAFT DRIVE AND PLUNGING	27
801B4500-01	JOINT ASSY	27
801B4600-02	SHAFT ASSY	27
801C1700-02	BEARING ASSY	27
801C1900-02	BEARING ASSY	27
801C4600-02	SHAFT ASSY	27
801D1700-02	BEARING ASSY	27
801D1900-01	BEARING ASSY	27

801D1900-02	BEARING ASSY	27
8054-01-0000	OVEN LH	25
8054-11-0000	OVEN LH	25
8054-51-0000	OVEN RH	25
8054-61-0000	OVEN RH	25
8054-69-0000	OVEN RH	25
8055515-4501	PRINTER MULTIPOINT	31
8061-632	FMU FUEL METER UNIT	73
8061-639	FMU FUEL METER UNIT	73
808050-4-066	EEC - ELECTRIC ENGINE CONTROL	73
808050-4-068	EEC - ELECTRIC ENGINE CONTROL	73
808050-5-068	EEC - ELECTRIC ENGINE CONTROL	73
810A0000-03	SERVO CONTROL RUDDER	27
810A0000-04	SERVO CONTROL RUDDER	27
810A0000-05	SERVO CONTROL RUDDER	27
810A0000-06	SERVO CONTROL RUDDER	27
810C0000-01	SERVO CONTROL RUDDER	27
810D0000-01	SERVO CONTROL RUDDER	27
810M0000-01	SERVO CONTROL RUDDER	27
810M0000-02	SERVO CONTROL RUDDER	27
8201-01-0000	OVEN	25
8201-11-0000	OVEN	25
8201-51-0000	OVEN	25
822-0297-020	RECEIVER VOR-MARKER	34
822-0299-020	RECEIVER ADF	34
822-0329-020	TRANSCEIVER DME	34
822-0330-020	TRANSCEIVER HF	23
822-0334-020	TRANSCEIVER RADIO ALTI	34
822-0336-020	TRANSPONDER ATC	34
822-0726-020	RECEIVER VOR-MARKER	34
822-0987-002	COUPLER ANTENNA HF	23

822-0987-003	COUPLER ANTENNA HF	23
822-0990-003	TRANSCEIVER HF	23
822-1044-020	TRANSCEIVER VHF COM	23
822-1047-020	TRANSCEIVER VHF COM	23
822-1047-030	TRANSCEIVER VHF COM	23
822-1152-121	MMR MULTI MODE RECEIVER	34
822-1152-122	MMR MULTI MODE RECEIVER	34
822-1250-020	TRANSCEIVER VHF	34
822-1287-120	TRANSCEIVER VHF	34
822-1287-121	TRANSCEIVER VHF	34
822-1293-332	COMPUTER TCAS	34
822-1330-001	ANTENNA GPS ACTIVE	34
822-1338-021	TRANSPONDER ATC	34
822-1349-401	SATELLITE DATA UNIT	23
822-1369-003	INTERMEDIATE GAIN ANTENNA	23
822-1405-401	SATELLITE DATA UNIT	23
822-1710-201	TRANSCEIVER WEATHER RADAR	34
822-1710-202	TRANSCEIVER WEATHER RADAR	34
822-1710-204	TRANSCEIVER WEATHER RADAR	34
822-1710-214	TRANSCEIVER WEATHER RADAR	34
822-1821-430	MMR MULTI MODE RECEIVER	34
822-2033-001	ANTENNA GPS ACTIVE	34
822-2325-020	INTEROGATOR DME	34
824972-11-024	EEC - ELECTRIC ENGINE CONTROL	73
824972-7-020	EEC - ELECTRIC ENGINE CONTROL	73
824972-7-022	EEC - ELECTRIC ENGINE CONTROL	73
824972-9-020	EEC - ELECTRIC ENGINE CONTROL	73
824972-9-022	EEC - ELECTRIC ENGINE CONTROL	73
824972-9-024	EEC - ELECTRIC ENGINE CONTROL	73
827A0000-02	GEARBOX	27
828A0000-01	GEARBOX	27

828A0000-02	GEARBOX	27
829A0000-02	ACTUATOR SLAT A	27
829B0000-01	ACTUATOR SLAT A	27
829C0000-01	ACTUATOR SLAT A	27
830A0000-02	ACTUATOR SLAT B	27
830C0000-01	ACTUATOR SLAT B	27
831A0000-02	BRAKE WING TIP	27
831A0000-05	BRAKE WING TIP	27
831B0000-01	BRAKE WING TIP	27
831C0000-01	BRAKE WING TIP	27
831C0000-02	BRAKE WING TIP	27
833A2100-01	SHAFT ASSY SLAT DRIVE	27
833A2800-01	SHAFT ASSY CONNECTION	27
833B0400-01	SHAFT ASSY	27
833C2300-02	BEARING ASSY	27
833C5200-02	BEARING ASSY	27
833D2300-02	BEARING ASSY	27
8-372-02	SENSOR PROXIMITY	27
8-372-04	SENSOR PROXIMITY	27
8378M12	COMPRESSOR AIR	38
8378M2	COMPRESSOR AIR	38
8401-01-0000	OVEN	25
840745	CAP ASSY	38
8410B1-104-105	CAMERA	23
8427-10-054	BELT ATTACHING	25
85-16-08836-05	MICROPHONE HAND	23
85-16-11494-05	MICROPHONE HAND	23
87232329V03	ADM - AIR DATA MODULE	34
87292325V04	AEVC - AVIONICS EQT VENTILATION COMPUTER	21
87292325V05	AEVC - AVIONICS EQT VENTILATION COMPUTER	21

87292325V06	AEVC - AVIONICS EQT VENTILATION COMPUTER	21
87292325V07	AEVC - AVIONICS EQT VENTILATION COMPUTER	21
879-2525-014	ATC - TCAS DUAL CONTROL PANEL	34
887673	PUMP-HYDRAULIC	29
89-01-07000	HANDSET COCKPIT	23
89-01-07010	HANDSET CABIN	23
89-01-07020	HANDSET CABIN	23
89-01-07032	HANDSET CABIN	23
89-01-07035	HANDSET CABIN	23
89-01-07042	HANDSET CABIN	23
89-01-07045	HANDSET CABIN	23
89-01-07062	HANDSET CABIN	23
89-01-07122	HANDSET CABIN	23
89-01-07125	HANDSET CABIN	23
89-01-07126	HANDSET CABIN	23
89-01-07125	HANDSET CABIN	23
89-01-07130	HANDSET CABIN	23
89-01-07152	HANDSET CABIN	23
89-01-07154	HANDSET CABIN	23
89-01-07155	HANDSET CABIN	23
89-01-07185	HANDSET CABIN	23
89-01-07250	HANDSET CABIN	23
89-01-07260	HANDSET CABIN	23
89-01-17122	HANDSET CABIN	23
89-01-17182	HANDSET CABIN	23
89-01-27000	HANDSET COCKPIT	23
887673	PUMP HYDRAULIC	29
8910-620	VALVE AIR MODULTING	79
891511-14	STATIONARY CYLINDER & VALVE ASSY	35
895877AF	EXTINGUISHER APU	26
89794015	OXYGEN CYLINDER & VALVE ASSY	35

89794050	OXYGEN CYLINDER & VALVE ASSY	35
89794077	OXYGEN CYLINDER & VALVE ASSY	35
89798050	OXYGEN CYLINDER & VALVE ASSY	35
89799015	OXYGEN CYLINDER & VALVE ASSY	35
899-0850-002	RADIO MANAGEMENT PANEL	23
899-0850-003	RADIO MANAGEMENT PANEL	23
899-0850-004	RADIO MANAGEMENT PANEL	23
8ES005045-00	PSU POWER SUPPLY UNIT	33
8ES005304-00	PSU POWER SUPPLY UNIT	33
8ES005309-00	PSU POWER SUPPLY UNIT	33
8ES403701-02	TRANSFORMER REAR NAVIGATION LIGHT	33
8ES403703-02	TRANSFORMER REAR NAVIGATION LIGHT	33
8ES455012-00	PSU POWER SUPPLY UNIT	33
8ES455012-06	POWER SUPPLY STROBE LIGHT	33
8ES455438-06	PSU POWER SUPPLY UNIT	33
8ES455438-07	POWER SUPPLY WING STROBE LIGHT	33
8ES455440-06	POWER SUPPLY TAIL STROBE LIGHT	33
8ES455967-01	POWER SUPPLY BEACON LIGHT	33
8ES455967-20	POWER SUPPLY BEACON LIGHT	33
8ES456222-01	POWER SUPPLY NAVIGATION STROBE LIGHT	33
8ES456294-00	POWER SUPPLY NAVIGATION STROBE LIGHT	33
8ES456513-01	POWER SUPPLY WING STROBE LIGHT	33
8TJ124GGR1	TRANSMITTER FUEL FLOW	73
8TJ124GHG1	TRANSMITTER FUEL FLOW	73
8TJ167GHH1	TRANSMITTER FUEL FLOW	73
8TJ167GHV1	TRANSMITTER FUEL FLOW	73
9022-15702-10	CONTROLLER PRESSURE CABIN	21
9023-15703-71	VALVE OUTFLOW	21
9023-15703-81	VALVE OUTFLOW	21
9024-15704-03	VALVE SAFETY	21
9024-15704-2	VALVE SAFETY	21

9025A0009-01	MOTOR HYDRAULIC SLAT & FLAP	27
9028A0004-01	PPU POSITION PICK OFF UNIT	27
903116243B5B7G8	DMU - DATA MANAGEMENT UNIT	31
903116243B5D4J5	DMU - DATA MANAGEMENT UNIT	31
9043110-16	IGNITION LEAD	74
9043110-18	LEAD IGNITION	74
9043110-3	LEAD IGNITION	74
9045405-7	IGNITION LEAD	74
9104A0009-02	SENSOR PRESSURE	21
9105A0005-01	SENSOR TEMPERATURE	21
9105A0005-02	SENSOR TEMPERATURE	21
9105A0007-01	SENSOR TEMPERATURE	21
9106A0005-02	SENSOR PRESSURE	21
9106A0006-02	SENSOR PRESSURE	21
9-217-44	TRANSMITTER FUEL FLOW	73
9-217-59	TRANSMITTER FUEL FLOW	73
9-217-94	TRANSMITTER FUEL FLOW	73
922-168-000-031	CABLE	77
9231-4-600	MODULE ELECTRONIC	27
9231-8-600	MODULE ELECTRONIC	27
930-2000-001	TRANSCEIVER WXR	34
930-3000-001	DRIVE WEATHER RADAR ANTENNA	34
930-3001-001	DRIVE WEATHER RADAR ANTENNA	34
930-4301-001	ANTENNA WEATHER RADAR	34
930-7002-001	MOUNTING TRAY	34
933260	HYDRAULIC PUMP RAT	29
9387M24P09	LEAD IGNITION	74
9387M24P16	LEAD IGNITION	74
9387M24P18	LEAD IGNITION	74
93A100-80	CVR - COCKPIT VOICE RECORDER	31
93A100-83	CVR - COCKPIT VOICE RECORDER	31

93A150-20	MODULE PREAMPLIFIER	23
93N6035	PANEL CONTROL	25
9045330-2	EXCITER	74
940-0351-001	COMPUTER TCAS	34
940-0351-005	COMPUTER TCAS	34
94-0501-00-001	TANK ASSY WATER POTABLE	38
94-0502-00-001	TANK ASSY WATER POTABLE	38
9508175	VALVE FLOAT VENT	28
9599-607-12352	ANTENNA-RADIO ALTIMETER	34
9599-607-14942	TRANSCEIVER RADIO	34
9599-607-14943	TRANSCEIVER RADIO	34
9599-614-03105	TRANSCEIVER DME	34
95N6088	EMERGENCY LOCATOR TRANSMITTER	23
95N6089	ELT SUPPORT	23
9632500-8001	CONTROL ASSY CABLE	38
9632501-0001	CONTROL ASSY CABLE	38
9632501-1001	CONTROL ASSY CABLE	38
963A0000-02	VALVE TRIM PRESSURE AIR	21
963B0000-01	VALVE TRIM PRESSURE AIR	21
964-0452-001	TRANSCEIVER HF	23
964-0452-012	TRANSCEIVER HF	23
964-0452-052	TRANSCEIVER HF	23
964-0453-001	COUPLER HF	23
965-0676-020	COMPUTER GPWC	34
965-0976-003-206-206	COMPUTER EGPWC	34
965-0976-010	COMPUTER EGPWC	34
965-1676-001	GPWC - GROUND PROXIMITY WARNING COMPUTER	34
965-1676-002	GPWC - GROUND PROXIMITY WARNING COMPUTER	34
965-1676-003	GPWC - GROUND PROXIMITY WARNING COMPUTER	34
965-1696-051	TRANSCEIVER VHF	23
9700-A1A-BF20B	OXYGEN CYLINDER PORTABLE ASSY	35
9700-A1A-BF23A	OXYGEN CYLINDER PORTABLE ASSY	35

9700-A1A-BF23B	OXYGEN CYLINDER PORTABLE ASSY	35
9700-C1A-BF20B	OXYGEN CYLINDER PORTABLE ASSY	35
9700-C1A-BF23A	OXYGEN CYLINDER PORTABLE ASSY	35
9700-C1A-BF23AN	OXYGEN CYLINDER PORTABLE ASSY	35
9700-C1A-BF23B	OXYGEN CYLINDER PORTABLE ASSY	35
9700-C1A-F23A	OXYGEN CYLINDER PORTABLE ASSY	35
9700-C1A-F23AM	OXYGEN CYLINDER PORTABLE ASSY	35
9700-C1A-F23AN	OXYGEN CYLINDER PORTABLE ASSY	35
9700-C1A-YY0N	OXYGEN CYLINDER PORTABLE ASSY	35
9700-F1A-BF23A	OXYGEN CYLINDER PORTABLE ASSY	35
9700-F1A-BF23AM	OXYGEN CYLINDER PORTABLE ASSY	35
9700-F1A-BF23AN	OXYGEN CYLINDER PORTABLE ASSY	35
9700-F1A-F23A	OXYGEN CYLINDER PORTABLE ASSY	35
974540	PUMP ELECTRIC	29
978690-9	VALVE BLEED AIR HIGHT PRESSURE	36
980-0800-064	PRAM	23
980-0800-118	PRAM	23
980-4700-003	RECORDER SSFDR	23
980-4700-019	RECORDER SSFDR	23
980-4700-042	RECORDER SSFDR	23
980-4750-001	RECORDER SSFDR	23
980-4750-002	RECORDER SSFDR	23
980-6020-001	CVR - COCKPIT VOICE RECORDER	23
980-6022-001	CVR - COCKPIT VOICE RECORDER	23
980-6032-020	CVR - COCKPIT VOICE RECORDER	23
980-6032-023	CVR - COCKPIT VOICE RECORDER	23
980-9900-001	AUDIO VIDEO REPRODUCER UNIT	23
A05000	ACTUATOR ELECTRICAL	24
A05B00	ACTUATOR ELECTRICAL	24
A06L00	ACTUATOR ELECTRICAL	29
A08000	ACTTUATOR LP FUEL	28

A25312-1	VALVE THROTTLE	32
A25313002	VALVE BRAKE SELECTOR	32
A25313002-1	VALVE BRAKE SELECTOR	32
A25313003	VALVE BRAKE SELECTOR	32
A25313003-1	VALVE BRAKE SELECTOR	32
A25313003-2	VALVE BRAKE SELECTOR	32
A25315	VALVE BRAKE PARKING	32
A25315020-2	VALVE BRAKE PARKING	32
A25315-1	VALVE BRAKE PARKING	32
A25316	VALVE DUAL SHUTTLE	32
A25316-1	VALVE DUAL SHUTTLE	32
A25316-101	VALVE DUAL SHUTTLE	32
A25316-1B	VALVE DUAL SHUTTLE	32
A25434006-3	VALVE DUAL EMERGENCY - BRAKE	32
A25461-103	VALVE SELECTOR - BRAKE	32
A25461-104	VALVE SELECTOR - BRAKE	32
A3068-1	STRUT ASSY FAN COWL	71
A3068-7	STRUT ASSY FAN COWL	71
A3068-9	STRUT ASSY FAN COWL	71
A3410-2	STRUT ASSY FAN COWL	71
A361-5	HOLD OPEN ROD	71
A361-9	HOLD OPEN ROD	71
A68982	SERVO-VALVE - STEERING WHEEL NLG	32
A68982-002	SERVO-VALVE - STEERING WHEEL NLG	32
A68982-004	SERVO-VALVE - STEERING WHEEL NLG	32
A88004	SERVOVALVE SPOILER	27
A88004-005	SERVOVALVE SPOILER	27
AA1051-00	VALVE SOLENOID	75
AA1056-00	VALVE SOLENOID	75
AA1060-00	VALVE SOLENOID	75
ABS-2013-1A	BATTERY PACK	24

AC68A100	MDDU - MULTIPURPOSE DISK DRIVE UNIT	31
AC68A200	MDDU - MULTIPURPOSE DISK DRIVE UNIT	31
AC69572	VALVE SOLENOID	75
AC69574	VALVE SOLENOID	75
AC69576	VALVE SOLENOID	36
AC69922	VALVE AIR	75
AC69924	VALVE BLEED	75
ACP2788AB04	ACP - AUDIO CONTROL PANEL	23
ACP2788AB05	ACP - AUDIO CONTROL PANEL	23
ACP2788AD01	ACP - AUDIO CONTROL PANEL	23
ACP2788AE01	ACP - AUDIO CONTROL PANEL	23
ACP2788AF01	ACP - AUDIO CONTROL PANEL	23
ACREM1A	MEGAPHONE	25
ACREM1D	MEGAPHONE	25
AD8650501	ACTUATOR HORIZONTAL	25
AE1502U02	MOTOR ASSY BRAKE FAN	32
AE707631-1	HOSE	73
AE707632-1	HOSE	73
AE73325K	COUPLING HALF	29
AE80531K	COUPLING HALF	29
AE80532N	COUPLING HALF	29
AE86195G	VALVE ASSY FILL	29
AE99119K	COUPLING	29
AL-EX15-200E-1	COFFEE MAKER ESPRESSO	25
AL-EX15-200E-2	COFFEE MAKER ESPRESSO	25
ALL195-202-0	HEAT SHIELD LH	78
ALL195-204-0	SELF SUPPORTED BLANKET LH	78
ALL404-802-0	HARNESS WIRING LH SIDE	78
AMU2790CB04	AMU - AUDIO MANAGEMENT UNIT	23
AMU2790CB06	AMU - AUDIO MANAGEMENT UNIT	23

AMU2790DB04	AMU - AUDIO MANAGEMENT UNIT	23
AMU2790DB06	AMU - AUDIO MANAGEMENT UNIT	23
AMU3514CS01	AMU - AUDIO MANAGEMENT UNIT	23
AMU4031LA130103	AMU - AUDIO MANAGEMENT UNIT	23
AMU4031LA140204	AMU - AUDIO MANAGEMENT UNIT	23
AMU4031SA110101	AMU - AUDIO MANAGEMENT UNIT	23
AMU4031SA120102	AMU - AUDIO MANAGEMENT UNIT	23
AMU4031SA130103	AMU - AUDIO MANAGEMENT UNIT	23
AMU4031SA140204	AMU - AUDIO MANAGEMENT UNIT	23
AP41116101	RECORDER SSFDR	31
AP71232101	CVR - COCKPIT VOICE RECORDER	31
APE5100	CLOCK ELECTRONIC	31
APE5100-1	CLOCK ELECTRONIC	31
APE5110	CLOCK ELECTRONIC	31
AR4709-11	CDLCU-COCKPIT DOOR LCK CU	52
AR4709-203	CDLCU-COCKPIT DOOR LCK CU	52
AR4709-303	CDLCU-COCKPIT DOOR LCK CU	52
AR4709-7	CDLCU-COCKPIT DOOR LCK CU	52
AR4710-1	PAD KEY	52
AR4714-7	STRIKE ELECTRIC CTR	52
AR4714-9	STRIKE ELECTRIC CTR	52
AR4714-11	STRIKE ELECTRIC CTR	52
AR4754-1	LATCH-DOOR CENTER	52
AR4922-1	PAD-KEY	52
AV2014586-11-2	CYLINDER OXYGEN PORTABLE	35
AV2014595	CYLINDER OXYGEN PORTABLE	35
AV2014595-11-2	CYLINDER OXYGEN PORTABLE	35
AV2014595-21-2	CYLINDER OXYGEN PORTABLE	35
B372ABM0710	SEC - SPOILER ELEVATOR COMPUTER	27
B372BAM0508	SEC - SPOILER ELEVATOR COMPUTER	27
B372BAM0509	SEC - SPOILER ELEVATOR COMPUTER	27

B372BAM0511	SEC - SPOILER ELEVATOR COMPUTER	27
B372CAM0100	SEC - SPOILER ELEVATOR COMPUTER	27
B397AAM0510	FLIGHT AUGMENTATION COMPUTER	22
B397BAM0513	FLIGHT AUGMENTATION COMPUTER	22
B397BAM0515	FLIGHT AUGMENTATION COMPUTER	22
B397BAM0617	FLIGHT AUGMENTATION COMPUTER	22
B397BAM0619	FLIGHT AUGMENTATION COMPUTER	22
B397BAM0621	FLIGHT AUGMENTATION COMPUTER	22
B397BAM0622	FLIGHT AUGMENTATION COMPUTER	22
B397BAM0623	FLIGHT AUGMENTATION COMPUTER	22
B397BAM0624	FLIGHT AUGMENTATION COMPUTER	22
B397CAM0102	FLIGHT AUGMENTATION COMPUTER	22
B398AAM0412	FMGC - FLIGHT MANAGEMENT GUIDE COMPUTER	22
B398BAM0209	FMGC - FLIGHT MANAGEMENT GUIDE COMPUTER	22
B398BCM0109	FMGC - FLIGHT MANAGEMENT GUIDE COMPUTER	22
B401ACM0506	CFDIU - COMPUTER DIGITAL INTERFACE UNIT	31
B401ACM0507	CFDIU - COMPUTER DIGITAL INTERFACE UNIT	31
B539AAM0206	COMPUTER FUEL QUANTITY	28
B539AAM0307	COMPUTER FUEL QUANTITY	28
B546CAM0104	FMGC - FLIGHT MANAGEMENT GUIDANCE COMPUTER	22
BA03603	GENERATOR APU AC AUX	24
BA03604	GENERATOR APU AC AUX	24
BA16501-01	GENERATOR APU AC AUX	24
BA51015-3	EXTINGUISHER	26
BA51015G3	EXTINGUISHER	26
BA51015GS3	EXTINGUISHER	26
BA51015S3	EXTINGUISHER	26
BC2065C	PANEL SECAL CODE	23
BHC1060-04	VALVE PRIORITY	29
BMA3603AA01	BOX AUDIO JUNCTION	34
C12404AA01	ATC - TCAS CONTROL PANEL	34

C12404AA02	ATC - TCAS CONTROL PANEL	34
C12404AB02	ATC - TCAS CONTROL PANEL	34
C12848AA01	RADIO MANAGEMENT PANEL	23
C12848CA01	RADIO MANAGEMENT PANEL	23
C12848CB01	RADIO MANAGEMENT PANEL	23
C12848DA01	RADIO MANAGEMENT PANEL	23
C12848EA01	RADIO MANAGEMENT PANEL	23
C12850AB02	FCU - FLIGHT CONTROL UNIT	22
C12850AC02	FCU - FLIGHT CONTROL UNIT	22
C12850AC03	FCU - FLIGHT CONTROL UNIT	22
C12850BB02	FCU - FLIGHT CONTROL UNIT	22
C12850BC02	FCU - FLIGHT CONTROL UNIT	22
C12858CA02	FLIGHT MANAGEMENT ENVEL	22
C12860AA02	CFDIU - CENTRAL FAULT DATA INTERFACE UNIT	31
C12860AA03	CFDIU - CENTRAL FAULT DATA INTERFACE UNIT	31
C12860AA04	CFDIU - CENTRAL FAULT DATA INTERFACE UNIT	31
C13042AA03	FMGC - FLIGHT MANAGEMENT GUIDANCE COMPUTER	22
C13042AA04	FMGC - FLIGHT MANAGEMENT GUIDANCE COMPUTER	22
C13042BA02	FMGC - FLIGHT MANAGEMENT GUIDANCE COMPUTER	22
C13042BA03	FMGC - FLIGHT MANAGEMENT GUIDANCE COMPUTER	22
C13042BA08	FMGC - FLIGHT MANAGEMENT GUIDANCE COMPUTER	22
C13043AA03	FMGC - FLIGHT MANAGEMENT GUIDANCE COMPUTER	22
C13043AA04	FMGC - FLIGHT MANAGEMENT GUIDANCE COMPUTER	22
C13206AA00	FAC-FLIGHT AUGMENTATION COMPUTER	22
C13207AA00	FMGC - FLIGHT MANAGEMENT GUIDANCE COMPUTER	22
C13207DA00	FMGC - FLIGHT MANAGEMENT GUIDANCE COMPUTER	22
C13208BA00	FMGC - FLIGHT MANAGEMENT GUIDANCE COMPUTER	22
C16221VA01	ISIS - INTEGRATED ELECTRONIC STANDBY INSTRUMENT	34
C16221WB01	ISIS - INTEGRATED ELECTRONIC STANDBY INSTRUMENT	34
C19266AA01	MCDU - MULTIPURPOSE CONTROL DISPLAY UNIT	22
C19266EA01	MCDU - MULTIPURPOSE CONTROL DISPLAY UNIT	22

C19298AF05	LIQUID CRISTAL DISPLAY UNIT	31
C19366AF05	LIQUID CRISTAL DISPLAY UNIT	31
C19BQ0014	RESERVOIR HYDRAULIC BLUE	29
C19BQ0016	RESERVOIR HYDRAULIC BLUE	29
C19DS0024	RESERVOIR HYDRAULIC GREEN	29
C19DS0026	RESERVOIR HYDRAULIC GREEN	29
C20103100	SERVO VALVE - BRAKE	32
C20103100-1	SERVO VALVE - BRAKE	32
C20103100-101	SERVO VALVE - BRAKE	32
C20103110	SERVO VALVE - BRAKE	32
C20103120	SERVO VALVE - BRAKE	32
C20103130	SERVO VALVE - BRAKE	32
C20103500	SERVO VALVE - BRAKE	32
C20103520	SERVO VALVE - BRAKE	32
C20105000	TACHOMETER	32
C20105000-1	TACHOMETER	32
C20105000-2	TACHOMETER	32
C20215000	TRANSMITTER BRAKE PEDAL	32
C202163392E34	BSCU - BRAKE STEERING CONTROL UNIT	32
C202163392E35	BSCU - BRAKE STEERING CONTROL UNIT	32
C20195000-2	WHEEL MLG	32
C20195000-3	WHEEL MLG	32
C20195000-4	WHEEL MLG FITTED WITH TIRE	32
C20195000-5	WHEEL MLG FITTED WITH TIRE	32
C20195001-3	WHEEL MLG FITTED WITH TIRE	32
C20195001-3-51	WHEEL MLG FITTED WITH TIRE	32
C20195002	WHEEL MLG	32
C20195002	WHEEL MLG	32
C20195002-1	WHEEL MLG	32
C20195002-1	WHEEL MLG	32
C20195002-2	WHEEL MLG	32

C20195002-2	WHEEL MLG	32
C20195002-2-51	WHEEL MLG FITTED WITH TIRE	32
C20195002-3	WHEEL MLG	32
C20195002-4	WHEEL MLG	32
C20195002-51	WHEEL MLG FITTED WITH TIRE	32
C20195152	WHEEL MLG	32
C20195152-1	WHEEL MLG	32
C20195152-2	WHEEL MLG	32
C20195152-2-51	WHEEL MLG FITTED WITH TIRE	32
C20195152-3	WHEEL MLG	32
C20195152-3-51	WHEEL MLG FITTED WITH TIRE	32
C20195152-3-53	WHEEL MLG FITTED WITH TIRE	32
C20195152-4	WHEEL MLG	32
C20195152-5	WHEEL MLG	32
C20195162	WHEEL MLG	32
C20195162A	WHEEL MLG	32
C20195162-33	WHEEL NLG	32
C20195162-51	WHEEL MLG FITTED WITH TIRE	32
C20195162-53	WHEEL MLG FITTED WITH TIRE	32
C20195162-58	WHEEL MLG FITTED WITH TIRE	32
C20206160	WHEEL HALF OUTER	32
C20225300	BRAKE ASSY	32
C20225300-1	BRAKE ASSY	32
C20225310	BRAKE ASSY	32
C20225310-1	BRAKE ASSY	32
C20225410	BRAKE ASSY	32
C20225410-1	BRAKE ASSY	32
C20225508	BRAKE ASSY MLG CARBON	32
C20225509	BRAKE ASSY MLG CARBON	32
C20225510	BRAKE ASSY MLG CARBON	32
C20229000	THERMOCOUPLE	32

C20229001	THERMOCOUPLE	32
C20374000-1	SERVO VALVE BRAKE	32
C20374000-2	SERVO VALVE BRAKE	32
C20449000	BRAKE ASSY	32
C20464001	SENSOR TEMPERATURE	32
C20500000	WHEEL MLG	32
C20500100	WHEEL MLG	32
C20500100-52	WHEEL MLG FITTED WITH TIRE	32
C20500100-53	WHEEL MLG FITTED WITH TIRE	32
C20534000	BRAKE ASSY	32
C20534000-1	BRAKE ASSY	32
C20534000-1	BRAKE ASSY MLG	32
C20534099	BRAKE ASSY MLG	32
C20534100	BRAKE ASSY MLG	32
C24592000-1	CYLINDER MASTER	32
C24703001-1	SELECTOR BRAKE PARKING	32
C24703001-201	SELECTOR BRAKE PARKING	32
C24703001-3	SELECTOR BRAKE PARKING	32
C24703001-301	SELECTOR BRAKE PARKING	32
C24703001-4	SELECTOR BRAKE PARKING	32
C24703001-401	SELECTOR BRAKE PARKING	32
C24703003	SELECTOR BRAKE PARKING	32
C24703003-1	SELECTOR BRAKE PARKING	32
C24730001-6	UPLOCK ASSY NLG	32
C24730001-9	UPLOCK ASSY NLG	32
C24730100	UPLOCK ASSY NLG DOOR	32
C24730100-3	UPLOCK ASSY NLG DOOR	32
C24736000-0-1	STEERING CONTROL	32
C24736000-0-2	STEERING CONTROL	32
C24736000-1	STEERING CONTROL	32
C24736000-2	STEERING CONTROL	32

C24736001-0-1	STEERING CONTROL	32
C24736001-0-2	STEERING CONTROL	32
C24736001-1	STEERING CONTROL	32
C24736001-2	STEERING CONTROL	32
C24736100-1	STEERING CONTROL	32
C24737002	MANIFOLD BRAKE ASSY	32
C24737002-4	MANIFOLD BRAKE ASSY	32
C24750000-4	HYDRAULIC CONTROL UNIT	32
C24750000-7	HYDRAULIC CONTROL UNIT	32
C24750000-712	HYDRAULIC CONTROL UNIT	32
C24750000-722B	HYDRAULIC CONTROL UNIT	32
C24757000	VALVE SAFETY	32
C24837101	MANIFOLD BRAKE ASSY	32
C24837101-2	MANIFOLD BRAKE ASSY	32
C24837101-3	MANIFOLD BRAKE ASSY	32
C24837102	MANIFOLD BRAKE ASSY	32
C24837102-2	MANIFOLD BRAKE ASSY	32
C24839010	ALTERNATE BRAKE MANIFOLD LH	32
C24839010-2	ALTERNATE BRAKE MANIFOLD LH	32
C24840010	ALTERNATE BRAKE MANIFOLD RH	32
C24840010-2	ALTERNATE BRAKE MANIFOLD RH	32
C24966000	VALVE SAFETY	32
C24966000-1	VALVE SAFETY	32
C24998000	VALVE SWIVEL SELECTOR	32
C25243002-2	VALVE SAFETY	32
C25243102	VALVE SAFETY	32
C51LM0020	VALVE FILLING	29
C82LL0010	VALVE DRAIN	29
C93R38-601	CANISTER PUMP FUEL	28
C93R38-606	CANISTER PUMP FUEL	28
CA146-00	THERMO COUPLE WIRING HARNESS	77

CA147-00	THERMO COUPLE WIRING HARNESS	77
CA148-00	THERMO COUPLE WIRING HARNESS	77
CA170-00	THERMO COUPLE WIRING HARNESS	77
CA170-01	THERMO COUPLE WIRING HARNESS	77
CA170-02	THERMO COUPLE WIRING HARNESS	77
CA171-00	THERMO COUPLE WIRING HARNESS	77
CA171-01	THERMO COUPLE WIRING HARNESS	77
CA171-02	THERMO COUPLE WIRING HARNESS	77
CA172-01	THERMO COUPLE WIRING HARNESS	77
CA172-02	THERMO COUPLE WIRING HARNESS	77
CA172-03	THERMO COUPLE WIRING HARNESS	77
CA172-04	THERMO COUPLE WIRING HARNESS	77
CA211-00	THERMO COUPLE WIRING HARNESS	77
CA212-00	THERMO COUPLE WIRING HARNESS	77
CA213-00	THERMO COUPLE WIRING HARNESS	77
CG1151AC03	CDU - CONTROL DISPLAY UNIT	34
CG7G0	SMOKE DETECTOR	26
CG7G010	SMOKE DETECTOR	26
CG7G0-10	SMOKE DETECTOR	26
CG1151AC03	CDU - CONTROL DISPLAY UNIT	34
CGDU2000-00	DETECTOR SMOKE	26
CGDU3000-00	DETECTOR SMOKE	26
CN120	VALVE MANUAL CONTROL	78
CT191B	VALVE CHECK	21
CZ9284E	TRANSDUCER PRESSURE	29
D05000	VALVE DRAIN	38
D05A00	VALVE DRAIN	38
D18309-101	RESERVOIR & VALVE ASSY	25
D18309-103	RESERVOIR & VALVE ASSY	25
D18309-105	RESERVOIR & VALVE ASSY	25
D18309-115	RESERVOIR & VALVE ASSY	25

D18309-201	RESERVOIR & VALVE ASSY	25
D1876-1000A	BRG COMPT AIR COOLER NO 4	75
D1876-5000A	BRG COMPT AIR COOLER NO 4	75
D23071001	NLG ACTUATING CYLINDER	32
D23076000-3	NLG UNLOCKING ACTUATOR	32
D23077000-1	LOCK SPRING NLG	32
D23081000	BEARING SWIVEL EG NLG	32
D23081020	SPHERICAL BEARING LEG NL	32
D23090000-6	PIVOTING DOOR REVERSER	32
D23090000-7	PIVOTING DOOR REVERSER	32
D23090000-8	PIVOTING DOOR REVERSER	32
D23116000	VALVE ANTI SHIMMY NLG	32
D23119000	BOX ELECTRICAL NLG	32
D23119100	BOX ELECTRICAL NLG	32
D23119500	BOX ELECTRICAL NLG	32
D23119500-1	BOX ELECTRICAL NLG	32
D23119510	BOX ELECTRICAL NLG	32
D23119510-1	BOX ELECTRICAL NLG	32
D23119550-1	BOX ELECTRICAL NLG	32
D23119600-1	BOX ELECTRICAL NLG	32
D23119700	BOX ELECTRICAL NLG	32
D23119700-1	BOX ELECTRICAL NLG	32
D23119750	BOX ELECTRICAL NLG	32
D23119750-1	BOX ELECTRICAL NLG	32
D23119751	BOX ELECTRICAL NLG	32
D23119751-1	BOX ELECTRICAL NLG	32
D23119760	BOX ELECTRICAL NLG	32
D23119760-1	BOX ELECTRICAL NLG	32
D23119761	BOX ELECTRICAL NLG	32
D23119770	BOX ELECTRICAL NLG	32
D23119770-1	BOX ELECTRICAL NLG	32

D23119771	BOX ELECTRICAL NLG	32
D23278100	FITTING ASSY TOWING	32
D23354000-2	BOX ELECTRICAL NLG	32
D23354100-2	BOX ELECTRICAL NLG	32
D23355020	SLEEVE ASSY AXLE NLG	32
D23611000	LOCK SPRING NLG	32
D23612000	LOCK LINK NLG	32
D23613000	NLG ACTUATING CYLINDER	32
D23627000	HARNESS UPPER ELECTRIC	32
D23628000-1	HARNESS UPPER ELECTRIC	32
D23809000	BOX ELECTRICAL NLG	32
D24001000	VALVE CONTROL	32
D24005000	MANIFOLD ALTERNATE BRAKE	32
D24005000-1	MANIFOLD ALTERNATE BRAKE	32
D24006000	MANIFOLD ALTERNATE BRAKE	32
D24006000-1	MANIFOLD ALTERNATE BRAKE	32
D2727000700200	ROD-SPRING RUDDER	27
D2727000700600	ROD-SPRING RUDDER	27
D30664-103	SLIDE FWD	25
D30664-105	SLIDE FWD	25
D30664-107	SLIDE FWD	25
D30664-109	SLIDE FWD	25
D30664-309	SLIDE FWD	25
D30664-409	SLIDE FWD	25
D30664-509	SLIDE FWD	25
D30664-513	SLIDE FWD	25
D30664-709	SLIDE FWD	25
D30665-103	SLIDE AFT	25
D30665-105	SLIDE AFT	25
D30665-107	SLIDE AFT	25
D30665-109	SLIDE AFT	25

D30665-309	SLIDE AFT	25
D30665-409	SLIDE AFT	25
D30665-509	SLIDE AFT	25
D30665-709	SLIDE AFT	25
D31516-119	SLIDE FWD	25
D31516-121	SLIDE FWD	25
D31516-123	SLIDE FWD	25
D31516-125	SLIDE FWD	25
D31516-315	SLIDE FWD	25
D31516-317	SLIDE FWD	25
D31516-415	SLIDE FWD	25
D31516-417	SLIDE FWD	25
D31516-519	SLIDE FWD	25
D31516-521	SLIDE FWD	25
D31516-523	SLIDE FWD	25
D31516-525	SLIDE FWD	25
D31516-615	SLIDE FWD	25
D31516-617	SLIDE FWD	25
D31516-621	SLIDE FWD	25
D31516-717	SLIDE FWD	25
D31516-721	SLIDE FWD	25
D31517-119	SLIDE AFT	25
D31517-121	SLIDE AFT	25
D31517-123	SLIDE AFT	25
D31517-125	SLIDE AFT	25
D31517-315	SLIDE AFT	25
D31517-317	SLIDE AFT	25
D31517-415	SLIDE AFT	25
D31517-417	SLIDE AFT	25
D31517-519	SLIDE AFT	25
D31517-521	SLIDE AFT	25

D31517-523	SLIDE AFT	25
D31517-525	SLIDE AFT	25
D31517-615	SLIDE AFT	25
D31517-617	SLIDE AFT	25
D31517-621	SLIDE AFT	25
D31517-715	SLIDE AFT	25
D31517-717	SLIDE AFT	25
D31517-721	SLIDE AFT	25
D31865-109	SLIDE OVERWING LH	25
D31865-110	SLIDE OVERWING RH	25
D31865-111	SLIDE OVERWING	25
D31865-112	SLIDE OVERWING	25
D31865-209	SLIDE OVERWING LH	25
D31865-210	SLIDE OVERWING RH	25
D31865-309	SLIDE OVERWING	25
D31865-310	SLIDE OVERWING	25
D41428	REDUCER PRESSURE	26
D41552	REDUCER PRESSURE	26
D5241025600200	DOOR ASSY	52
D5241025600240	DOOR ASSY	52
D5241025600300	DOOR ASSY	52
D5311001800100	WINDOW SLIDING ASSY RH	56
D5311001800602	WINDOW SLIDING ASSY LH	56
D5311001800655	WINDOW SLIDING ASSY LH	56
D5311001800656	WINDOW SLIDING ASSY LH	56
D5311001800702	WINDOW SLIDING ASSY RH	56
D5311001801402	WINDOW SLIDING ASSY LH	56
D5311001801451	WINDOW SLIDING ASSY LH	56
D5311001801452	WINDOW SLIDING ASSY LH	56
D5311001801552	WINDOW SLIDING ASSY RH	56
D5311001801704	WINDOW SLIDING ASSY RH	56

D5311001801801	WINDOW SLIDING ASSY LH	56
D5311001802201	WINDOW SLIDING ASSY LH	56
D5311001802601	WINDOW SLIDING ASSY LH	56
D5311001802651	WINDOW SLIDING ASSY LH	56
D5311001802652	WINDOW SLIDING ASSY LH	56
D5311001802653	WINDOW SLIDING ASSY LH	56
D5311001802701	WINDOW SLIDING ASSY RH	56
D5311001802751	WINDOW SLIDING ASSY RH	56
D5311001802752	WINDOW SLIDING ASSY RH	56
D5311001802753	WINDOW SLIDING ASSY RH	56
D5311001802801	WINDOW SLIDING ASSY LH	56
D5311001802901	WINDOW SLIDING ASSY RH	56
D5311001802903	WINDOW SLIDING ASSY RH	56
D5311001803001	WINDOW SLIDING ASSY LH	56
D5311001803051	WINDOW SLIDING ASSY LH	56
D5311001803101	WINDOW SLIDING ASSY RH	56
D5311001803151	WINDOW SLIDING ASSY RH	56
D5311001803201	WINDOW SLIDING ASSY LH	56
D5311001803203	WINDOW SLIDING ASSY LH	56
D5311001803251	WINDOW SLIDING ASSY LH	56
D5311001803301	WINDOW SLIDING ASSY RH	56
D5311001803303	WINDOW SLIDING ASSY RH	56
D5311001803351	WINDOW SLIDING ASSY RH	56
D5311001803701	WINDOW SLIDING ASSY RH	56
D5311001900100	WINDOW SLIDING ASSY RH	56
D5311001900200	WINDOW SLIDING ASSY LH	56
D5311001900201	WINDOW SLIDING ASSY LH	56
D5311001900400	WINDOW SLIDING ASSY LH	56
D5311001900401	WINDOW SLIDING ASSY LH	56
D5311001900701	WINDOW SLIDING ASSY RH	56
D5311001900702	WINDOW SLIDING ASSY RH	56
D5311001900801	WINDOW SLIDING ASSY LH	56

D5311001901201	WINDOW SLIDING ASSY LH	56
D5311001901301	WINDOW SLIDING ASSY RH	56
D5311001901351	WINDOW SLIDING ASSY RH	56
D5311001901601	WINDOW SLIDING ASSY LH	56
D5311001901651	WINDOW SLIDING ASSY LH	56
D5311001901701	WINDOW SLIDING ASSY RH	56
D5311001901751	WINDOW SLIDING ASSY RH	56
D5311001901801	WINDOW SLIDING ASSY LH	56
D5311001901901	WINDOW SLIDING ASSY RH	56
D5311001902001	WINDOW SLIDING ASSY LH	56
D5311001902101	WINDOW SLIDING ASSY RH	56
D5311001902201	WINDOW SLIDING ASSY LH	56
D5311001902301	WINDOW SLIDING ASSY RH	56
D5311001902601	WINDOW SLIDING ASSY LH	56
D5311001902701	WINDOW SLIDING ASSY RH	56
D5311001904401	WINDOW SLIDING ASSY LH	56
D5311001904501	WINDOW SLIDING ASSY RH	56
D5311001904701	WINDOW SLIDING ASSY RH	56
D5311047700003	RADOME	53
D5311047700004	RADOME	53
D5311047700005	RADOME	53
D5311047700006	RADOME	53
D5311047700007	RADOME	53
D53132010000	RADOME	53
D53132110000	RADOME	53
D5313211000051	RADOME	53
D53132210000	RADOME	53
D5735002101308	WING TIP RH	57
D5735007100400Z	WING TIP FENCE LH	57
D5735120000200	WING TIP FENCE LH	57
D5735120000200A	WING TIP FENCE LH	57

D5735120000300A	WING TIP FENCE RH	57
D5746010000500	SLAT N1 RH	27
D5746010000700	SLAT N1 RH	27
D5746016800000	SLAT N1 LH	57
D5746016800100	SLAT N1 RH	27
D5746019800000	SLAT N1 LH	27
D5746019800100	SLAT N1 RH	27
D5746019800300	SLAT N1 RH	57
D5746027700100	SLAT N2 RH	57
D5746027700200	SLAT N2 LH	57
D5746027700300	SLAT N2 RH	57
D5746027800000	SLAT N2 LH	27
D5746027800100	SLAT N2 RH	57
D5746027800200	SLAT N2 LH	27
D5746027800800	SLAT N2 LH	57
D5746029800000	SLAT N2 LH	27
D5746029800100	SLAT N2 RH	27
D5746037700100	SLAT N3 RH	57
D5746037700200	SLAT N3 LH	57
D5746037700300	SLAT N3 RH	27
D5746037800000	SLAT N3 LH	57
D5746037800100	SLAT N3 RH	57
D5746037800600	SLAT N3 LH	57
D5746037800700	SLAT N3 RH	57
D5746037801000	SLAT N3 LH	57
D5746039800000	SLAT N3 LH	27
D5746039800100	SLAT N3 RH	57
D5746047700100	SLAT N4 RH	27
D5746047700200	SLAT N4 LH	57
D5746047700300	SLAT N4 RH	57

D5746047700500	SLAT N4 RH	57
D5746047800000	SLAT N4 LH	57
D5746047800100	SLAT N4 RH	57
D5746047800600	SLAT N4 LH	57
D5746047800700	SLAT N4 RH	57
D5746049800000	SLAT N4 LH	27
D5746049800100	SLAT N4 RH	27
D5746057700200	SLAT N5 LH	57
D5746057700300	SLAT N5 RH	57
D5746059800000	SLAT N5 LH	27
D5746059800100	SLAT N5 RH	27
D5746059801100	SLAT N5	27
D5746060000000	SLAT N1 LH	27
D5746060000100	SLAT N1 RH	27
D5746060000600	SLAT N1 LH	57
D5746060000700	SLAT N1 RH	57
D5746060000800	SLAT N1 LH	27
D5746067700200	SLAT N1 LH	57
D5746067700300	SLAT N1 RH	57
D5746067700400	SLAT N1 LH	57
D5746067700500	SLAT N1 RH	57
D5746091000000	SLAT N1 LH	57
D5746091000100	SLAT N1 RH	57
D5746091000200	SLAT N1 LH	57
D5746091000300	SLAT N1 RH	57
D5746091000400	SLAT N1 LH	57
D5746091000500	SLAT N1 RH	57
D5746092000000	SLAT N2 LH	57
D5746092000200	SLAT N2 LH	57
D5746093000000	SLAT N3 LH	57

D5746093000100	SLAT N3 RH	57
D5746093000200	SLAT N3 LH	57
D5746093000300	SLAT N3 RH	57
D5746093000400	SLAT N3 LH	57
D5746093000500	SLAT N3 RH	57
D5746094000000	SLAT N4 LH	57
D5746094000100	SLAT N4 RH	57
D5746094000200	SLAT N4 RH	57
D5746094000300	SLAT N4 RH	57
D5746094000400	SLAT N4 RH	57
D5746094000500	SLAT N4 RH	57
D5757030500200	STRUT INTERCONNECTING	57
D5757030500200G	STRUT INTERCONNECTING	27
D5757030500600	STRUT INTERCONNECTING	57
D5757030500800	STRUT INTERCONNECTING	57
D5757030501500	STRUT INTERCONNECTING	27
D5757030501600	STRUT INTERCONNECTING	57
D5757030501700	STRUT INTERCONNECTING	27
D5757030501900	STRUT INTERCONNECTING	57
D5757032200000	STRUT INTERCONNECTING	57
D5757032200200	STRUT INTERCONNECTING	57
D5757032201100	STRUT INTERCONNECTING	57
D5757033400000	SEAL ASSY LH	57
D5757050001200	FLAP INBOARD STRUCTURE LH	27
D5757050001300	FLAP INBOARD STRUCTURE RH	27
D5757059100200	SUPPORT ASSY TORSION LH	57
D5757065000200	FLAP INBOARD LH	57
D5757065000300	FLAP INBOARD RH	57
D5757065001400	INNER FLAP EQUIPPED LH	57
D5757065002000	INNER FLAP EQUIPPED LH	57

D5757065002100	INNER FLAP EQUIPPED RH	57
D5757065002200	FLAP INBOARD LH	57
D5757065002300	FLAP INBOARD RH	57
D5757065002600	FLAP INBOARD LH	57
D5757065002700	FLAP INBOARD RH	57
D5757065002800	INNER FLAP EQUIPPED LH	57
D5757065002900	INNER FLAP EQUIPPED RH	57
D5757065003000	INNER FLAP EQUIPPED LH	57
D5757065003100	INNER FLAP EQUIPPED RH	57
D5757065003300	INNER FLAP EQUIPPED RH	57
D5757065003400	INNER FLAP EQUIPPED LH	57
D5757065003500	INNER FLAP EQUIPPED RH	57
D5757065003700	INNER FLAP EQUIPPED RH	57
D5757065003800	FLAP INNBORD LH	27
D5757065003900	FLAP INNBORD RH	27
D5757065004200	FLAP INNBORD LH	27
D5757065004300	FLAP INNBORD RH	27
D5757420200300	FLAP OUTBOARD RH	57
D5764000001118A	AILERON ASSY RH	57
D5775000200000Z	SPOILER N2 LH	27
D5775000300000Z	SPOILER N3 LH	57
D5775000400000Z	SPOILER N4 LH	57
D5775001600018A	SPOILER N1 LH	57
D5775001600118A	SPOILER N1 RH	57
D5775001700017A	SPOILER N1 LH	57
D5775001700018A	SPOILER N1 LH	57
D5775001700117A	SPOILER N1 RH	57
D5775001700118A	SPOILER N1 RH	57
D5775001700217A	SPOILER N1 LH	57
D5775001700237A	SPOILER N1 LH	57

D5775001700317A	SPOILER N1 RH	57
D5775001700337A	SPOILER N 1 RH	57
D5775001800018A	SPOILER N 2 LH	57
D5775001800118A	SPOILER N 2 RH	57
D5775001900000A	SPOILER N2 LH	57
D5775001900017A	SPOILER N2 LH	57
D5775001900018A	SPOILER N2 LH	57
D5775001900100A	SPOILER N2 RH	57
D5775001900117A	SPOILER N2 RH	57
D5775001900118A	SPOILER N2 RH	57
D5775001900217A	SPOILER N2 LH	57
D5775001900237A	SPOILER N2 LH	57
D5775001900317A	SPOILER N2 RH	57
D5775001900337A	SPOILER N2 RH	57
D5775001900500A	SPOILER N2 RH	57
D5775002000017A	SPOILER N3 LH	57
D5775002000018A	SPOILER N3 LH	57
D5775002000100A	SPOILER N3 RH	57
D5775002000117A	SPOILER N3 RH	57
D5775002000118A	SPOILER N3 RH	57
D5775002000217A	SPOILER N3 LH	57
D5775002000237A	SPOILER N3 LH	57
D5775002000238A	SPOILER N3 LH	57
D5775002000317A	SPOILER N3 RH	57
D5775002000337A	SPOILER N3 RH	57
D5775002000338A	SPOILER N3 RH	57
D5775002100017A	SPOILER N4 LH	57
D5775002100018A	SPOILER N4 LH	57
D5775002100100A	SPOILER N4 RH	57
D5775002100117A	SPOILER N4 RH	57

D5775002100118A	SPOILER N4 RH	57
D5775002100217A	SPOILER N4 LH	57
D5775002100237A	SPOILER N4 LH	57
D5775002100238A	SPOILER N4 LH	57
D5775002100317A	SPOILER N4 RH	57
D5775002100337A	SPOILER N 4 RH	57
D5775002100338A	SPOILER N 4 RH	57
D5775002200017A	SPOILER N5 LH	57
D5775002200018A	SPOILER N5 LH	57
D5775002200117A	SPOILER N5 RH	57
D5775002200118A	SPOILER N5 RH	57
D5775002200217A	SPOILER N5 LH	57
D5775002200237A	SPOILER N5 LH	57
D5775002200238A	SPOILER N5 LH	57
D5775002200317A	SPOILER N5 RH	57
D5775002200337A	SPOILER N5 RH	57
D5775002200338A	SPOILER N5 RH	57
D5775612200000Z	SPOILER N2 LH	27
D5775612200100Z	SPOILER N2 RH	27
D90ST2002-000	GAUGE TRANSMITTER	29
D90ST2003-000	SWITCH LOW LEVEL	29
DK120	UNDERWATER LOCATOR BEACON	23
DV3454A00	FAN SPEED CONTROLLER	21
DV8456701-4	TLU - TRAVEL LIMIT UNIT	27
DV8456701-5	TLU - TRAVEL LIMIT UNIT	27
DVE90-06	VALVE SOLENOID	35
DVE90-07	VALVE SOLENOID	35
E03A00	VALVE ASSY FIRE SHUTOFF	29
E20000	ACTUATOR HYDRAULIC	52
E21324000-2	TRANSMITTER BRAKE PEDAL	32

E21327004	BSCU - BRAKE STEERING CONTROL UNIT	32
E21327006	BSCU - BRAKE STEERING CONTROL UNIT	32
E21327007	BSCU-BRAKING AND STEERING CONTROL UNIT	32
E21327106	BSCU - BRAKE STEERING CONTROL UNIT	32
E21327107	BSCU-BRAKING AND STEERING CONTROL UNIT	32
E21337006	BSCU-BRAKING AND STEERING CONTROL UNIT	32
E21337007	BSCU-BRAKING AND STEERING CONTROL UNIT	32
E61751-00-0001	REDUCER PRESSURE	26
E61751-00-0002	HALON PRESSURE REDUCER	26
E61751-00-0003	REDUCER-PRESSURE	26
E28180-10	PBE	35
E28180-20-0001	PBE	35
ED43A1D5	FLIGHT DATA INTERFACE UNIT	31
ED43A1D6	FLIGHT DATA INTERFACE UNIT	31
ED45A100	DATA MANAGEMENT UNIT	31
ED45A300	DATA MANAGEMENT UNIT	31
ELP362D	UNDERWATER LOCATOR BEACON	23
EVR750-04-0100A	VDR - VHF DATA RADIO	23
EVT174-500E	FAN BRAKE MOTOR	32
EVT3454	FAN AVIONICS	21
EVT3454G	FAN AVIONICS	21
EVT3454H	FAN AVIONICS	21
EVT3454HC	FAN AVIONICS	21
EVT3454J	FAN AVIONICS	21
EVT3454J01	FAN AVIONICS	21
FE171-000	REGULATOR CABLE TENSION	27
FE240-0021	CYLINDER DOOR DAMPER	52
FE240-003	CYLINDER DOOR DAMPER	52
FE240-0031	CYLINDER DOOR DAMPER	52
FE240-004	CYLINDER DOOR DAMPER	52
FE240-005	CYLINDER DOOR DAMPER	52

FE240-006	CYLINDER DOOR DAMPER	52
FE240-007	CYLINDER DOOR DAMPER	52
FE412000104	SSU - SIDE STICK UNIT CAPTAIN	27
FE412000105	SSU - SIDE STICK UNIT FIRST OFFICER	27
FE412000106	SSU - SIDE STICK UNIT CAPTAIN	27
FE412000107	SSU - SIDE STICK UNIT FIRST OFFICER	27
FRH100002A	SWITCH PRESSURE	28
FRH220034V	VALVE ASSY NON RETURN	36
FRH230003C	VALVE PRESSURE	38
FRH280002	VALVE RELIEF PRESSURE	28
FRH340002B	VALVE DRAIN WATER	38
FRH340003H	VALVE DRAIN WATER	38
G6990-32	PANEL ATC	34
G6990-40	PANEL ATC	34
G6992-10	PANEL ATC	34
GAI2800-02	SMOKE DETECTOR	26
GMT4200	CLOCK ELECTRONIC	31
GMT4200-1	CLOCK ELECTRONIC	31
GPA1202-00	SMOKE DETECTOR	26
HAD19795	THERMOCOUPLE	77
HC1750	VALVE ANTI ICE WING	30
HC1751	VALVE ANTI ICE WING	30
HC1752	VALVE ANTI ICE WING	30
HC1755	VALVE ANTI ICE WING	30
HC1756	VALVE ANTI ICE WING	30
HC1757	VALVE ANTI ICE WING	30
HC1758	VALVE ANTI ICE WING	30
HG1150AC06	ADIRU - AIR DATA INERTIAL REFERENCE UNIT	34
HG1150AC07	ADIRU - AIR DATA INERTIAL REFERENCE UNIT	34
HG2021GA03	GPS SENSOR UNIT	34
HG2030AC09	ADIRU - AIR DATA INERTIAL REFERENCE UNIT	34

HG2030AC11	ADIRU - AIR DATA INERTIAL REFERENCE UNIT	34
HG2030AD09	ADIRU - AIR DATA INERTIAL REFERENCE UNIT	34
HG2030AD11	ADIRU - AIR DATA INERTIAL REFERENCE UNIT	34
HG2030AE21	ADIRU - AIR DATA INERTIAL REFERENCE UNIT	34
HG2030AE22	ADIRU - AIR DATA INERTIAL REFERENCE UNIT	34
HG2030AE23	ADIRU - AIR DATA INERTIAL REFERENCE UNIT	34
HG2030BE03	ADIRU - AIR DATA INERTIAL REFERENCE UNIT	34
HG2030BE04	ADIRU - AIR DATA INERTIAL REFERENCE UNIT	34
HR2769-8	STRUT ASSY	71
HFE95-20D	COFFEE MAKER ESPRESSO	25
HTE190001	ACTUATOR TWIN	28
HTE190001-1	ACTUATOR TWIN	28
HTE190001-2	ACTUATOR TWIN	28
HTE190026	ACTUATOR TWIN	28
HTE200002	ACTUATOR FUEL	28
HTE200002-1	ACTUATOR FUEL	28
HTE490012	VALVE NON RETURN	28
HTE510016	VALVE-GAS CHARGING	28
HTE690047	SWITCH PRESSURE	28
HTE900087-001	VALVE TRANSFER	28
HTE900095	VALVE TRANSFER	28
HTE900096	VALVE TRANSFER	28
HTE900118-001	VALVE LOW PRESSURE FUEL	28
HTE900133	VALVE FUEL	28
HTE900135	VALVE FUEL	28
HTE900189	VALVE CONTROL FUEL	28
J172ABM	ACCELEROMETER	27
J172ABM01	ACCELEROMETER	27
K217ABM11	FCU - FLIGHT CONTROL UNIT	22
K226ABM3	MCDU - MULTIFONCTION CONTROL DISPLAY UNIT	22
K226ABM4	MCDU - MULTIFONCTION CONTROL DISPLAY UNIT	22
K226ABM5	MCDU - MULTIFONCTION CONTROL DISPLAY UNIT	22

L83A602	VALVE WATER DRAIN	28
L83A13-604	VALVE-WATER DRAIN	28
L83A13-609	VALVE-WATER, DRAIN	28
L83A13-610	WATER DRAIN VALVE	28
L83A13-611	VALVE WATER DRAIN	28
L83A13-614	VALVE WATER DRAIN	28
L83A13-615	VALVE WATER DRAIN	28
L83A13-616	VALVE WATER DRAIN	28
L83A13-617	MONITOR LEAK	28
L95F50-603	PROTECTOR-OVERPRESSURE	28
LA2T0G20705B050	ATSU - AIR TRAFFIC SERVICES UNIT	34
LA2T0G20705C070	ATSU - AIR TRAFFIC SERVICES UNIT	34
LA2T0G21006CA10	ATSU - AIR TRAFFIC SERVICES UNIT	34
LA2T0J00000D0F1	DISK - AIR TRAFFIC SERVICES UNIT	34
LA2T0J00000N0F1	DISK - AIR TRAFFIC SERVICES UNIT	34
LA2T0J00003A0F1	DISK - AIR TRAFFIC SERVICES UNIT	34
LA2T0J0S2EZ03F1	SOFTWARE - ATSU ROUTER	34
LA2T0J0S2MX01F1	SOFTWARE - ATSU ROUTER	34
LA2T0J0S4EZ02F1	SOFTWARE - ATSU ROUTER	34
LA2T0J0S4EZ04F1	SOFTWARE - ATSU ROUTER	34
LA2T0J0S4NZ04F1	SOFTWARE - ATSU ROUTER	34
LA2T0J60002C0F1	SOFTWARE - ATSU CONFIG	34
LA2T0S11105F0F1	SOFTWARE - A/C INTERFACE	34
M83P1801A	MIC -HAND MICROPHONE	23
MC10-04-109	OXYGEN MASK REGULATOR	35
MC10-08-103	OXYGEN MASK REGULATOR	35
MC10-08-107	OXYGEN MASK REGULATOR	35
MC10-08-109	OXYGEN MASK REGULATOR	35
MC10-08-123	OXYGEN MASK REGULATOR	35
MC10-08-127	OXYGEN MASK REGULATOR	35
MC10-08-209	OXYGEN MASK REGULATOR	35

MC10-17-100	OXYGEN MASK REGULATOR	35
MC10-25-101	OXYGEN MASK REGULATOR	35
MC10-25-104	OXYGEN MASK REGULATOR	35
MC10-25-124	OXYGEN MASK REGULATOR	35
MF10-02-11	FULL FACE OXYGEN MASK	35
MF10-04-01	FULL FACE OXYGEN MASK	35
MF10-05-11	MASK OXYGEN FULL FACE	35
MF20-003	FULL FACE OXYGEN MASK	35
MF20-534	MASK OXYGEN FULL FACE	35
MXP401	STOWAGE BOX ASSY	35
MXP402	STOWAGE BOX ASSY	35
MXP410-1	STOWAGE BOX ASSY	35
MXP410-2	STOWAGE BOX ASSY	35
MXP801-1	STOWAGE BOX ASSY	35
MXP801-10	STOWAGE BOX ASSY	35
MXP801-11	STOWAGE BOX ASSY	35
MXP801-51	STOWAGE BOX ASSY	35
MXP806-4	STOWAGE BOX ASSY	35
MXP806-5	STOWAGE BOX ASSY	35
MI585306-402	TRANSCEIVER WEATHER RADAR	34
MI585311-421	WRCP - WEATHER RADAR CONTROL PANEL	34
MI585461-401	WRDU - WEATHER RADAR DRIVE UNIT	34
N40-1A10100-101	HANDSET COCKPIT	23
N40-1A40212-102	HANDSET INTERPHONE	23
N40-1B10100-000	HANDSET FLIGHT DECK PAX	23
N40-1B10100-101	HANDSET ASSY-COCKPIT	23
N40-1B10138-101	HANDSET ASSY-COCKPIT	23
N40-1B20212-102	HANDSET ASSY CABIN	23
N40-1B20215-000	HANDSET CABIN PAX	23
N40-1B30215-102	HANDSET ASSY CABIN	23

N40-1B40212-102	HANDSET ASSY CABIN	23
NH25216-1	WINDOW SLIDING LH	56
NH25216-141	WINDOW FIXED LH	56
NH25216-142	WINDOW FIXED RH	56
NH25216-2	WINDOW SLIDING RH	56
NH25216-349	WINDOW	56
NH25216-350	WINDOW FIXED RH	56
NP165331-1	WINDSHIELD MAIN LH 1	56
NP165331-2	WINDSHIELD MAIN RH 1	56
NP165312-13	WINDOW SIDE LH 2	56
NP165312-14	WINDOW RH SIDE 2	56
NP165332A1	WINDOW ASSEMBLY LH SIDE 2	56
NP165332A2	WINDOW ASSEMBLY LH SIDE 2	56
NP165332B1	WINDOW PANE SIDE LH 2	56
NP165332B2	RH SIDE WINDOW PANE RH SIDE 2	56
NP165332C1	FRAME RETAINER KIT	56
NP165332C2	FRAME RETAINER KIT	56
NP165333A1	WINDOW ASSEMBLY LH SIDE 3	56
NP165333A2	WINDOW ASSEMBLY RH SIDE 3	56
NP165333A3	WINDOW ASSEMBLY LH SIDE 3	56
NP165333A4	WINDOW ASSEMBLY RH SIDE 3	56
NP165333B1	WINDOW PANE LH SIDE 3	56
NP165333B2	WINDOW PANE LH SIDE 3	56
NP165333C1	FRAME RETAINER KIT	56
NP165333C2	FRAME RETAINER KIT	56
P1801A	MIC - HAND MICROPHONE	23
P99C38-601	PUMP FUEL	28
P99C38-605	PUMP FUEL	28
PAI2800	SMOKE DETECTOR	26
PAI2800-01	SMOKE DETECTOR	26
PAI2830-00	SMOKE DETECTOR	26

PC01502	TRANSFORMER CURRENT	24
PC01801	TRANSFORMER CURRENT	24
PC6033-3-55	RECORDER QAR	31
PG1152AC03	ADM AIR DATA MODULE	34
PG1152AC04	ADM AIR DATA MODULE	34
PG1152AC05	ADM AIR DATA MODULE	34
PG1152BC02	ADM AIR DATA MODULE	34
PPA1100-00	SMOKE DETECTOR	26
PPA1101-00	SMOKE DETECTOR	26
PPA1102-00	SMOKE DETECTOR	26
PPA1201-00	SMOKE DETECTOR	26
PPA1202-00	SMOKE DETECTOR	26
PPA1203-00	SMOKE DETECTOR	26
PPC1100-00	SMOKE DETECTOR	26
PPC1200-00	SMOKE DETECTOR	26
QA07638ISS1	INDICATOR CLOGGING	79
R2955530-1	ROLLER	25
RAI2800M0706	SDCU - SMOKE DETECTOR CONTROL UNIT	26
RCF6705	REGULATOR PRESSURE	35
RCF6708	REGULATOR PRESSURE	35
RD-AV4001-01	BOX JUNCTION	23
RD-AV4001-11	BOX JUNCTION	23
RD-AV9809-01	MONITOR LCD - LH	23
RD-AV9810-01	MONITOR LCD - RH	23
RD-AX7271	REPRODUCER ANNOUCEMENT TAPE	23
RD-AX7271AF02	REPRODUCER ANNOUCEMENT TAPE	23
RD-AX7675-51	REPRODUCER ANNOUCEMENT TAPE	23
RP152-01	SENSOR TEMPERATURE T25	73
RP159-00	SENSOR TEMPERATURE T12	73
RP183-00	SENSOR TEMPERATURE T12	73
RP198-00	SENSOR TEMPERATURE T12	73
RP198-01	SENSOR TEMPERATURE T12	73

RP198-02	SENSOR TEMPERATURE T12	73
RP216-00	SENSOR TEMPERATURE T25	73
RPCU9167-01	CONTROL UNIT	21
RU1502U01	FAN WHEEL BRAKE	32
S1820513-15	PANEL REMOTE CONTROL	25
S1821502-02	ELT-EMERGENCY LOCATOR TRANSMITTER	25
S1823502-05	ELT-EMERGENCY LOCATOR TRANSMITTER	25
S1851501-01	ELT-EMERGENCY LOCATOR TRANSMITTER	25
S200-0012-00	RECORDER SSFDR	31
S4-3300520	ACUATOR HYDRAULIC	52
S4-3300520-01	ACUATOR HYDRAULIC	52
S4-3400900	VALVE MANUAL	52
S4-3400900-01	VALVE MANUAL	52
S4-3401310-03	VALVE SAFETY	52
S4-3401310-04	VALVE SAFETY	52
S4-3402180	VALVE ELECTRO SELECTOR	52
S4-3500711	MANIFOLD GROUND SERVICE	29
S4-3500712	MANIFOLD GROUND SERVICE	29
S800-2000-00	RECORDER SSFDR	31
S800-3000-00	RECORDER SSFDR	31
SAS911-001A	VALVE ANTI ICE WING	30
SAS911-002A	VALVE ANTI ICE WING	30
SAS912-001A	VALVE ANTI ICE WING	30
SAS912-002A	VALVE ANTI ICE WING	30
SB209L1A1-1483	ACCUMULATOR HYDRAULIC	29
SB209L1A1-1484	ACCUMULATOR HYDRAULIC	29
SC4700-3	ACTUATOR SERVO - YAW DAMPER	27
SC4700-4	ACTUATOR SERVO - YAW DAMPER	27
SC4700-5	ACTUATOR SERVO - YAW DAMPER	27
SC4800-9	SERVOCONTROL ELEVATOR	27
SC4800-92	SERVOCONTROL ELEVATOR	27

SC4800-93	SERVOCONTROL ELEVATOR	27
SC4800-10	SERVOCONTROL ELEVATOR	27
SC4800-103	SERVOCONTROL ELEVATOR	27
SC4800-11	SERVOCONTROL ELEVATOR	27
SC4800-113	SERVOCONTROL ELEVATOR	27
SIC5059-04-0107	COMPUTER FQI	28
SIC5059-04-0207	COMPUTER FQI	28
SIC5059-11-0107	COMPUTER FQI	28
SIC5059-11-0207	COMPUTER FQI	28
SIC5059-13-10	COMPUTER FQI	28
SIC5059-13-20	COMPUTER FQI	28
SIC5059-14-31	COMPUTER FQI	28
ST3100-21-10	HANDSET CABIN	23
ST3100-22-10	HANDSET CABIN	23
ST3100-22-24	HANDSET CABIN	23
ST3100-23-10	HANDSET CABIN	23
ST3100-23-24	HANDSET CABIN	23
ST3100-23-26	HANDSET CABIN	23
ST3100-23-32	HANDSET CABIN	23
ST3100-33-10	HANDSET CABIN	23
SPSA320-3-3-2	WINDOW SLIDING LH	56
SPSA320-4-3-2	WINDOW SLIDING RH	56
SPSA320-5-2-2	WINDOW FIXED LH	56
SPSA320-6-2-2	WINDOW FIXED RH	56
SPSA320-7-3-2	WINDOW SLIDING	56
SPSA320-7-4-2	WINDOW SLIDING LH	56
SPSA320-8-3-2	WINDOW SLIDING	56
SPSA320-8-4-2	WINDOW SLIDING RH	56
SPSA320-9-2-2	WINDOW FIXED LH	56
SPSA320-10-2-2	WINDOW FIXED RH	56
STA320-1-8-2	WINDSHIELD	56

TAAI1-03CE00-02	SEAT FIRST OFFICER RH	25
TAAI1-03CE01-01	SEAT FIRST OFFICER	25
TAAI1-03CE01-02	SEAT FIRST OFFICER	25
TAAI1-03CE10-02	SEAT FIRST OFFICER	25
TAAI1-03CE11-02	SEAT FIRST OFFICER	25
TAAI1-03PE00-01	SEAT ASSY-CAPTAIN	25
TAAI1-03PE00-02	SEAT CAPTAIN	25
TAAI1-03PE01-02	SEAT CAPTAIN	25
TAAI1-03PE02-02	SEAT CAPTAIN	25
TAAI1-03PE03-02	SEAT CAPTAIN	25
TAAI1-03PE10-02	SEAT CAPTAIN	25
TAAI1-03PE11-02	SEAT CAPTAIN	25
TAAI1-03PE13-02	SEAT CAPTAIN	25
TAAI1-404000-04	FITTING EQUIPPED	25
TAAI1-993000-05	ARMREST CAPTAIN	25
TAAI2-33CE00-01	SEAT FIRST OFFICER	25
TAAI2-33CE01-01	SEAT ASSY-FIRST OFFICER	25
TAAI2-33CE10-01	SEAT FIRST OFFICER	25
TAAI2-33CE11-01	SEAT FIRST OFFICER	25
TAAI2-33CE20-01	SEAT FIRST OFFICER	25
TAAI2-33CE21-01	SEAT FIRST OFFICER	25
TAAI2-33CE30-01	SEAT FIRST OFFICER ELECTRICALLY OPERATED	25
TAAI2-33CE31-01	SEAT CAPTAIN	25
TAAI2-33PE00-01	SEAT CAPTAIN LH	25
TAAI2-33PE01-01	SEAT CAPTAIN LH	25
TAAI2-33PE10-01	SEAT CAPTAIN	25
TAAI2-33PE11-01	SEAT CAPTAIN	25
TAAI2-33PE20-01	SEAT CAPTAIN	25
TAAI2-33PE21-01	SEAT CAPTAIN	25
TAAI2-33PE30-01	SEAT CAPTAIN ELECTRICALLY OPERATED	25
TAAI2-33PE31-01	SEAT CAPTAIN	25

TAAI3-03CE00-01	SEAT FIRST OFFICER RH	25
TAAI3-03CE01-01	SEAT FIRST OFFICER RH	25
TAAI3-03CE02-01	SEAT FIRST OFFICER	25
TAAI3-03CE10-01	SEAT FIRST OFFICER	25
TAAI3-03CE11-01	SEAT FIRST OFFICER	25
TAAI3-03CE12-01	SEAT FIRST OFFICER	25
TAAI3-03CE20-01	SEAT FIRST OFFICER	25
TAAI3-03CE21-01	SEAT FIRST OFFICER	25
TAAI3-03CE22-01	SEAT FIRST OFFICER	25
TAAI3-03CE30-01	SEAT FIRST OFFICER	25
TAAI3-03CE31-01	SEAT FIRST OFFICER	25
TAAI3-03CE32-01	SEAT FIRST OFFICER	25
TAAI3-03PE00-01	SEAT CAPTAIN LH	25
TAAI3-03PE01-01	SEAT CAPTAIN	25
TAAI3-03PE02-01	SEAT CAPTAIN	25
TAAI3-03PE10-01	SEAT CAPTAIN	25
TAAI3-03PE11-01	SEAT CAPTAIN	25
TAAI3-03PE12-01	SEAT CAPTAIN	25
TAAI3-03PE20-01	SEAT CAPTAIN	25
TAAI3-03PE21-01	SEAT CAPTAIN	25
TAAI3-03PE22-01	SEAT CAPTAIN	25
TAAI3-03PE31-01	SEAT CAPTAIN	25
TAAI3-03PE32-01	SEAT CAPTAIN	25
TC194-00	THERMO COUPLE WIRING HARNESS	77
TC195-00	THERMO COUPLE WIRING HARNESS	77
TC199-00	SENSOR TEMPERATURE T5	77
TC199-01	SENSOR TEMPERATURE T5	77
TC201-00	SENSOR TEMPERATURE OIL	79
TC201-01	SENSOR TEMPERATURE OIL	79
TC254-01	THERMO COUPLE WIRING HARNESS	77

TC254-02	THERMO COUPLE WIRING HARNESS	77
TC255-01	THERMO COUPLE WIRING HARNESS	77
TC255-02	THERMO COUPLE WIRING HARNESS	77
TC255-03	THERMO COUPLE WIRING HARNESS	77
TC255-04	THERMO COUPLE WIRING HARNESS	77
TC266-00	SENSOR TEMPERATURE T5	77
TC266-01	SENSOR TEMPERATURE T5	77
TC315-00	THERMO COUPLE WIRING HARNESS	77
TC315-01	THERMO COUPLE WIRING HARNESS	77
TC315-02	THERMO COUPLE WIRING HARNESS	77
TC316-00	THERMO COUPLE WIRING HARNESS	77
TC316-01	THERMO COUPLE WIRING HARNESS	77
TC316-02	THERMO COUPLE WIRING HARNESS	77
TLS755-01-0101B	MMR - MULTI MODE RECEIVER	34
TLS755-01-0102A	MMR - MULTI MODE RECEIVER	34
TM113-1	TRANSDUCER AND SWITCH TEMP	29
TY1540-24	CONTROL UNIT	78
TY1541-50	ACTUATOR NON LOCKING	78
TY1541-51	ACTUATOR NON LOCKING	78
TY1542-50	ACTUATOR LOCKING	78
TY1544-20	DRIVE UNIT	78
TY2013-2A	HYDRAULIC CONTROL UNIT	78
TY2013-10	HYDRAULIC CONTROL UNIT	78
TY2013-10A	HYDRAULIC CONTROL UNIT	78
TY2013-10C	HYDRAULIC CONTROL UNIT	78
TY2013-10E	HYDRAULIC CONTROL UNIT	78
TY2013-11	HYDRAULIC CONTROL UNIT	78
TY2013-11A	HYDRAULIC CONTROL UNIT	78
TY2092-01	HYDRAULIC CONTROL UNIT	78
TY2092-12	HYDRAULIC CONTROL UNIT	78
TY2092-21	HYDRAULIC CONTROL UNIT	78

TY2092-22	HYDRAULIC CONTROL UNIT	78
TY2092-23	HYDRAULIC CONTROL UNIT	78
V2T127B	VALVE BUTTERFLY	21
V2T127D	VALVE BUTTERFLY	21
V2T152B	VALVE BUTTERFLY	21
V2T152D	VALVE BUTTERFLY	21
VD3810	FAN MIXED FLOW	21
VD3810-10	FAN MIXED FLOW	21
VD3820	FAN MIXED FLOW	21
VD3820-10	FAN MIXED FLOW	21
VD3900-02	FAN RECIRCULATION	21
VD3900-03	FAN RECIRCULATION	21
VD3901-00	FAN RECIRCULATION	21
VD3909-00	FAN RECIRCULATION	21
VD3920	FAN EXTRACTION	21
VFT210	SKIN VALVE AIR INLET	21
VFT210A	SKIN VALVE AIR INLET	21
VFT210A1	SKIN VALVE AIR INLET	21
VFT210A2	SKIN VALVE AIR INLET	21
VFT210B00	SKIN VALVE AIR INLET	21
VFT300	SKIN VALVE AIR OUTLET	21
VFT300A	SKIN VALVE AIR OUTLET	21
VFT300A1	SKIN VALVE AIR OUTLET	21
VFT300B00	SKIN VALVE AIR OUTLET	21
VR3910	FAN EXTRACTION	21
VT442-2	INDICATOR WATER QUANTITY	38
VT477	INDICATOR QTY HYDRAULIC	29
VT477-1	INDICATOR QTY HYDRAULIC	29
VT477-2	INDICATOR QTY HYDRAULIC	29
VT477-3	INDICATOR QTY HYDRAULIC	29
Y005-2	TRU - TRANSFORMER RECTIFIER UNIT	24
Y005-3	TRU - TRANSFORMER RECTIFIER UNIT	24

Z010H0003113	DIRECTOR CDIS	23
Z010H0005118	DIRECTOR CDIS	23
Z010H0005119	DIRECTOR CDIS	23
Z010H000520A	DIRECTOR CDIS	23
Z010H000521A	DIRECTOR CDIS	23
Z014H000030C	DIRECTOR CDIS	23
Z014H000031A	DIRECTOR CDIS	23
Z014H000131A	DIRECTOR CDIS	23
Z020H0001112	PTP - PROGRAMMING AND TEST PANEL	23
Z030H0003110	DEU - DECODER ENCODER UNIT A	23
Z030H0004110	DEU - DECODER ENCODER UNIT A	23
Z030H0005110	DEU - DECODER ENCODER UNIT A	23
Z031H0001110	DEU - DECODER ENCODER UNIT A	23
Z031H0002110	DEU - DECODER ENCODER UNIT A	23
Z033H0001110	DEU - DECODER ENCODER UNIT A	23
Z033H0002110	DEU - DECODER ENCODER UNIT A	23
Z040H0003110	DEU - DECODER ENCODER UNIT B	23
Z033H0003112	DEU - DECODER ENCODER UNIT B	23
Z040H0004110	DEU - DECODER ENCODER UNIT B	23
Z040H0005110	DEU - DECODER ENCODER UNIT B	23
Z040H0006110	DEU - DECODER ENCODER UNIT B	23
Z040H000720A	DEU - DECODER ENCODER UNIT B	23
Z040H000820A	DEU - DECODER ENCODER UNIT B	23
Z043H000150A	DEU - DECODER ENCODER UNIT B	23
Z043H000250A	DEU - DECODER ENCODER UNIT B	23
Z043H000351A	DEU - DECODER ENCODER UNIT B	23
Z050H0042011	CAM - CABIN ASSIGN MODULE	23
Z050H0042021	CAM - CABIN ASSIGN MODULE	23
Z050H0069120	CAM - CABIN ASSIGN MODULE	23
Z050H0069211	CAM - CABIN ASSIGN MODULE	23
Z050H0075121	CAM - CABIN ASSIGN MODULE	23
Z050H6042032	CAM - CABIN ASSIGN MODULE	23

Z050H6042050	CAM - CABIN ASSIGN MODULE	23
Z050H8401790	CAM - CABIN ASSIGN MODULE	23
Z050H8401840	CAM - CABIN ASSIGN MODULE	23
Z050H8401860	CAM - CABIN ASSIGN MODULE	23
Z050H8401870	CAM - CABIN ASSIGN MODULE	23
Z050H8401910	CAM - CABIN ASSIGN MODULE	23
Z050H8401920	CAM - CABIN ASSIGN MODULE	23
Z050H8401930	CAM - CABIN ASSIGN MODULE	23
Z050H8401940	CAM - CABIN ASSIGN MODULE	23
Z050H8401950	CAM - CABIN ASSIGN MODULE	23
Z050H8401960	CAM - CABIN ASSIGN MODULE	23
Z050H8401972	CAM - CABIN ASSIGN MODULE	23
Z050H8401990	CAM - CABIN ASSIGN MODULE	23
Z050H8401A00	CAM - CABIN ASSIGN MODULE	23
Z050H8401A20	CAM - CABIN ASSIGN MODULE	23
Z050H8401A30	CAM - CABIN ASSIGN MODULE	23
Z050H8401A50	CAM - CABIN ASSIGN MODULE	23
Z050H8401A60	CAM - CABIN ASSIGN MODULE	23
Z050H8401A70	CAM - CABIN ASSIGN MODULE	23
Z050H8401A80	CAM - CABIN ASSIGN MODULE	23
Z050H8401B00	CAM - CABIN ASSIGN MODULE	23
Z050H8401B10	CAM - CABIN ASSIGN MODULE	23
Z111H0020110	AIP - ATTENDANT INDICATION PANEL	23
Z111H0020112	AIP - ATTENDANT INDICATION PANEL	23
Z111H0022112	AIP - ATTENDANT INDICATION PANEL	23
Z111H0023112	AIP - ATTENDANT INDICATION PANEL	23
Z111H0023151	AIP - ATTENDANT INDICATION PANEL	23
Z111H0030151	AIP - ATTENDANT INDICATION PANEL	23
Z111H0033130	AIP - ATTENDANT INDICATION PANEL	23
Z111H0033131	AIP - ATTENDANT INDICATION PANEL	23
Z111H0033151	AIP - ATTENDANT INDICATION PANEL	23
Z111H0037130	AIP - ATTENDANT INDICATION PANEL	23

Z111H0037131	AIP - ATTENDANT INDICATION PANEL	23
Z120H030530B	AAP - ADDITIONAL ATTENDANT	23
Z120H050530B	AAP - ADDITIONAL ATTENDANT	23
Z120H050830B	AAP - ADDITIONAL ATTENDANT	23
Z120H050930B	AAP - ADDITIONAL ATTENDANT	23
Z120H057530B	AAP - ADDITIONAL ATTENDANT	23
Z130H0080110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0087110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0089110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0109110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0126110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0152110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0199110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0201110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0235110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0236110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0238110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0242110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0609110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0699110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0700110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0701110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0735110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0736110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0738110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0742110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0798110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0799110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0801110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0802110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0803110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0804110	FAP - FORWARD ATTENDANT PANEL	23

Z130H0805110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0806110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0807110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0808110	FAP - FORWARD ATTENDANT PANEL	23
Z130H0809110	FAP - FORWARD ATTENDANT PANEL	23
Z133H030150B	FAP - FORWARD ATTENDANT PANEL	23
Z133H031151A	FAP - FORWARD ATTENDANT PANEL	23
Z133H031351A	FAP - FORWARD ATTENDANT PANEL	23
Z133H031651A	FAP - FORWARD ATTENDANT PANEL	23
Z133H031851A	FAP - FORWARD ATTENDANT PANEL	23
Z133H031G51A	FAP - FORWARD ATTENDANT PANEL	23
Z133H052151D	FAP - FLIGHT ATTENDANT PANEL	23
Z133H052551C	FAP - FLIGHT ATTENDANT PANEL	23
Z133H052551D	FAP - FLIGHT ATTENDANT PANEL	23
Z133H052D51C	FAP - FLIGHT ATTENDANT PANEL	23
Z133H052D51D	FAP - FLIGHT ATTENDANT PANEL	23
Z133H053151E	FAP - FLIGHT ATTENDANT PANEL	23
Z133H053551E	FAP - FLIGHT ATTENDANT PANEL	23
Z133H053751E	FAP - FLIGHT ATTENDANT PANEL	23
Z133H053D51E	FAP - FLIGHT ATTENDANT PANEL	23
Z145H0042120	FAP - FLIGHT ATTENDANT PANEL	23
Z212H0000110	CONTROL UNIT - WATER HEATING	30
Z212H0001110	CONTROL UNIT - WATER HEATING	30
Z212H0002110	CONTROL UNIT - WATER HEATING	30
Z212H0010110	CONTROL UNIT - WATER HEATING	30
Z220H0000110	CONTROL UNIT - DRAIN MAST	30
Z220H0001110	CONTROL UNIT - DRAIN MAST	30
Z220H0002110	CONTROL UNIT - DRAIN MAST	30
Z272H0000114	MCU - MASTER CONTROL UNIT	25
Z312H08G9006	PIP - PURSER INFORMATION PA	23
Z312H08GM00E	PANEL - PASSENGER INFORMATION	23

Z315H017010A	PSU - PASSENGER SERVICE UNIT	23
Z315H0GA0006	PIP - PURSER INFORMATION PA	23
Z315H2000110	PISA - PASSENGER INTERFACE	23
Z317H0150105	PSU - PASSENGER SERVICE UNIT	23
Z317H0170105	PSU - PASSENGER SERVICE UNIT	23
Z317H0370205	PSU - PASSENGER SERVICE UNIT	23
Z317H2000110	PSU - PASSENGER SERVICE UNIT	23
Z351H0000110	PISA - PASSENGER INTERFACE	23
ZAW623-01	TRANSDUCER-PRESSURE	29
ZRA380-00	TRANSDUCER-PRESSURE	36

